

# e-Manual SPT — 7000series

Leading the way with Reliability, Features and Value






# SPT-7000

## How to use e-Manual

- Introduction
- System Installation ▶
- System Use ▶
- System Expansion & Dismantle ▶
- Appendix A  
System Set-Up
- Appendix B  
System Structure



Exit PDF e-Manual

Print e-Manual page

Help Contnets

Show all titles of of e-Manual

Move to the first page

Move to the next page.

Page Number

Move to the previous page.

Click these text button to move each chapter



E-Manual

SPT-7000series

PDF electronic manual consists of System Instruction, System Installation, System Use, System Setup, System Expansion and Appendix a/b.

Contents

| Introduction  | System Installation  | System Use  | System Expansion & Dismantle   | Appendix A System Set-Up   | Appendix B System Structure  |
|---|--|---|--|--|--|
| <div>Notification</div> <div> <div>Notification</div> <div>References</div> <div>Alert message &amp; symbol</div> </div> <div>Unpacking</div> <div>System Features</div> <div> <div>System Introduction</div> <div>System Features</div> <div>System Specifications</div> </div> <div>Part Name and Function</div> <div> <div>Front View</div> <div>Half-Side View</div> <div>Side View</div> <div>Rear View</div> </div> | <div>Make sure of installation area</div> <div>Before connecting peripherals</div> <div>Connecting Peripherals</div> <div> <div>Connecting Serial Port Devices such as Barcode Scanner</div> <div>Connecting RJ-11 Cash Drawer</div> <div>Connecting RJ-45 LAN Cable</div> <div>Connecting USB Device</div> <div>Connecting PS Module</div> <div>Connecting Security / Scanner Module</div> <div>Connecting Receipt Printer</div> <div>Receipt Printer</div> <div>Dismantle the Cover for Customer Displays</div> <div>Connecting DVR Card</div> <div>Connecting AC Power Cord to the Set Plug</div> <div>Cable Management</div> </div> <div>System On / Off</div> <div> <div>System On</div> <div>System Off</div> </div> | <div>Keyboard Use</div> <div>Touch screen Use</div> <div>About POS Driver and Utility</div> <div>Dual Monitor Use</div> | <div>System Dismantling &amp; Assembling</div> <div>HDD Replacement</div> <div>Internal Speaker &amp; USB Removal</div> <div>Receipt Printer &amp; Board Removal</div> <div>Scanner &amp; Dallas Removal</div> <div>SMPS Removal</div> <div>Mainboard ASSY Removal</div> <div>Various Boards Removal</div> <div>Main Memory Removal</div> <div>Remove Display Assembly</div> <div>Remove MSR</div> <div>Remove Display Board</div> <div>Remove Touch Panel &amp; LCD</div> | <div>System Set-up Preview</div> <div>Main Menu</div> <div>Advanced Menu</div> <div>Chipset Menu</div> <div>Boot Menu</div> <div>Security Menu</div> <div>Save &amp; Exit Menu</div> | <div>System Block</div> <div>Mainboard Overview</div> <div>Exploded View</div> |



# SPT-7000

Introduction

- Notification
  - Notification
  - References
  - Alert message & symbol
- Unpacking
- System Features
- Part Name and Function

System Installation ▶

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

Introduction

## 01. Notificaton

References

# Thank you for your purchase of Sam4s POS terminal.

This e-Manual provides you with technical information such as electrical circuit, components and structure regarding Sam4s POS (Point of Sale) System SPT-7000.

- The outer design or specifications are subject to change for quality improvement without prior notice.

[Notice to Users]

This device classified for the commerce is compatible with A-Class Electromagnetic Wave Registration.  
So, it is recommended to be used in shops or stores outside households.



# SPT–7000

Introduction

- Notification
  - Notification
  - References**
  - Alert message & symbol
- Unpacking
- System Features
- Part Name and Function

System Installation ▶

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set–Up

Appendix B  
System Structure

## Introduction

# 01. Notificaton

## References

- The contents of this manual is subject to change without prior notice.
- This manual cannot be copied or duplicated without Sam4s approval.
- The copyright of the e–Manual is in Sam4s.
- Some equipment nomenclature and abbreviations used here may differ from that contained in other Sam4s publications.
- This device complies with part 15 of the FCC Rules. (Class A digital device)



# SPT-7000

Introduction

- Notification
  - Notification
  - References
  - Alert message & symbol
  - Unpacking
  - System Features
  - Part Name and Function

System Installation ▶

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## Introduction

# 01. Notificaton

## Alert message & symbol

- This manual uses the following conventions to show the alert messages. An alert message consists of an alert signal and alert statements.  
The alert signal consists of an alert symbol and a signal word or just a signal word. The following are the alert signals and their meanings:



This indicates a hazardous situation likely to result in serious personal injury if the user does not perform the procedure correctly.



This indicates a hazardous situation could result in personal injury if the user does not perform the procedure correctly.



This indicates a hazardous situation could result in minor or moderate personal injury if the user does not perform the procedure correctly.  
This alert signal also indicates that damages to the product or other property may occur if the user does not perform the procedure correctly.



This indicates information that could help the user use the product more efficiently.



# SPT-7000

## Introduction

- Notification
- Unpacking
- System Features
- Part Name and Function

## System Installation

## System Use

## System Expansion & Dismantle

## Appendix A System Set-Up

## Appendix B System Structure

## Introduction

### 02. Unpacking



〈System Terminal〉



〈Mouse / Mouse Pad (Option)〉



〈Keyboard (Option)〉



〈Quick Manual〉



〈Power Cable〉



# SPT-7000

Introduction

- Notification
- Unpacking
- System Features
- System Introduction
- System Features
- System Specifications
- Part Name and Function

System Installation

System Use

System Expansion  
& Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

Introduction

## 03. System Features

System Introduction

- This POS system supports All-in-one type and Separable type. Also, you can organize the cables easily in any surrounding.
- This POS system can make all-in-one touch screen, internal printer, MSR, SCR and customer display. And installation is easy and convenient.
- It is convenient to change Hard Disk Drive and Memory and supports OS recovery function and Virus Vaccine program.

System Features

- 15” TFT LCD Touch Screen
- Internal Printer (Option)
- MSR (Magnetic Stripe Reader) (Option)
- SCR (Smart Card Reader) (Option)
- 7” or 15” Size Customer Display (Option)
- Barcode Scanner (Option)
- Fingerprint Reader or Magnet Dallas (Option)
- Cfast Module (Option)



SPT-7000

Introduction

- Notification
- Unpacking
- System Features
- System Introduction
- System Features
- System Specifications
- Part Name and Function

System Installation

System Use

System Expansion  
& Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

Introduction

03. System Features

System Specifications

General Specifications

|                |   |
|----------------|---|
| Dimension      | 267(357) X 310 X 387(447) ( ):With Display  |
| Weight         | 11.5 Kgs (based on standard specification)  |
| Processor      | CPU : Intel Atom Cedarview D2550 1.86GHZ (Dual Core) FANLESS HEAT SINK  |
| Chipset        | Southbridge : Intel NM10  |
| Storage        | 2 x 2.5 inch HDD (SATA type) / SSD / Cfast  |
| I/O Interface  | Serial Connector : DSUB 9-pin x 3 (COM1,2,4)+RJ45 port x 1 (COM3)<br>COM1,2,3,4 : 5V or 12V or RI Output (BIOS setting)<br>Parallel Connector : 25-pin x 1<br>USB 2.0 Connector : Left Side x 2, Rear Side x 4<br>LAN Connector : RJ45 port x 1 (8-pin)<br>Cash Drawer : RJ11 port x 1 (6-pin)<br>VGA Connector : VGA port x 1 (15-pin)<br>DC Output Jack : 12V output port x 1<br>Audio : Line Out x 1, Line In x 1, MIC x 1 |
| OS             | Windows XP / 2000 / WEPOS 등 / POSReady 2009 / POSReady 7  |
| Main Memory    | DDR3 SODIMM Socket (up to 4GB)  |
| Booting Device | HDD, SSD, Cfast Memory, CD/DVD ROM Drive, USB Memory  |
| BIOS           | AMI(Amerian Megatrends, Inc.) BIOS  |



SPT-7000

Introduction

- Notification
- Unpacking
- System Features
- System Introduction
- System Features
- System Specifications
- Part Name and Function

System Installation

System Use

System Expansion  
& Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

Introduction

03. System Features

System Specifications

General Specifications

|              |   |
|--------------|---|
| Display      | 15" TFT LCD, LVDS Interface<br>Resolution & Colors : 1024 x 768 (XGA), 16.2M (RGB) Color<br>Contrast Ratio : 450 : 1<br>Viewing Angle : Left-Right 150' / Up-Down 130' (Left 75' / Right 75' / Up 70' / Down 60')<br>Backlight Type : 2-CCFL<br>Backlight Brightness : 250 cd/m²<br>Backlight MTBF : 50,000 Hours |
| Touch Panel  | 15" 5-Wire Resistive Type<br>Interface : Serial COM5<br>Transparency : 80%<br>Surface Hardness : 3H<br>Hitting Life : 35 million times  |
| Power Supply | 60W Adaptor<br>AC INPUT : AC 100~240V / 50~60Hz, 2.0A<br>DC OUTPUT : 12V / 5.0A   |



SPT-7000

Introduction

- Notification
- Unpacking
- System Features
- System Introduction
- System Features
- System Specifications
- Part Name and Function

System Installation

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

Introduction

03. System Features

System Specifications

Specifications for Optional Devices

|                              |  |                 |  |   |
|------------------------------|--|-----------------|--|---|
| Receipt Printer              | 2-inch / 3-inch Thermal Printer<br>USB / SERIAL Interface<br>270mm/sec (3-inch), 150mm/sec (2-inch) speed<br>180 dpi resolution<br>Guillotine Type Auto-Cut (Jam-free) |                 |  | Power Supply<br>60W Adaptor<br>AC INPUT : AC 100V ~ 240V / 50Hz ~ 60Hz 1.5A<br>DC OUTPUT : 24V / 2.5A |
| Touch Panel                  | 15" True Flat Resistive Touch  |                 |  |   |
| Customer Display             | CDP  | 20 CHAR × 2Line | 7" TFT LCD, VGA (800 × 480)<br>15" TFT LCD, XGA(1024 × 768)<br>– Power Supply Change<br>80W Adaptor<br>AC INPUT : AC 100V ~ 240V / 50Hz ~ 60Hz 1.5A<br>DC OUTPUT : 12V / 6.67A |   |
| 5 × 7 Dot VFD                |  |                 |  |   |
| 256 × 32 Graphic Dot,        |  |                 |  |   |
| MSR (Magnetic Stripe Reader) | Read Track : ISO Track 1&2&3<br>Interface : USB<br>Performance Speed : 630BPS ~ 11,550BPS<br>Head Reliability : 400,000 times  |                 |  |   |
| DALLAS KEY                   | Magnet Type  |                 |  |   |
| Finger Printer Reader        | Fingerprint function, USB Commuication   |                 |  |   |
| CFast SOCKET                 | Possible to use CFast Memory   |                 |  |   |
| RAISER CARD                  | Various types of DVR Card installable including XV400PCI (Max. Channel 4 ports)  |                 |  |   |
| Scanner                      | 1D / 2D Barcode Recognition, USB Commuication  |                 |  |   |
| Smart Card Reader            | IC Card readable, USB Commuication   |                 |  |   |



# SPT-7000

## Introduction

- Notification
- Unpacking
- System Features
- Part Name and Function

- Front View
- Half-Side View
- Side View
- Rear View

## System Installation

## System Use

## System Expansion & Dismantle

## Appendix A System Set-Up

## Appendix B System Structure

### Introduction

## 04. Part Name and Function

### Front View





# SPT-7000

## Introduction

- Notification
- Unpacking
- System Features
- Part Name and Function
- Front View
- Half-Side View
- Side View
- Rear View

## System Installation

## System Use

## System Expansion & Dismantle

## Appendix A System Set-Up

## Appendix B System Structure

### Introduction

## 04. Part Name and Function

### Half-Side View





# SPT-7000

## Introduction

- Notification
- Unpacking
- System Features
- Part Name and Function
- Front View
- Half-Side View
- Side View
- Rear View

## System Installation

## System Use

## System Expansion & Dismantle

## Appendix A System Set-Up

## Appendix B System Structure

### Introduction

## 04. Part Name and Function

### Side View





# SPT-7000

## Introduction

- Notification
- Unpacking
- System Features
- Part Name and Function

- Front View
- Half-Side View
- Side View
- Rear View

## System Installation

## System Use

## System Expansion & Dismantle

## Appendix A System Set-Up

## Appendix B System Structure

### Introduction

## 04. Part Name and Function

### Rear View





# SPT-7000

## Introduction

- Notification
- Unpacking
- System Features
- Part Name and Function

- Front View
- Half-Side View
- Side View
- Rear View

## System Installation

## System Use

## System Expansion & Dismantle


## Appendix A System Set-Up

## Appendix B System Structure

### Introduction

## 04. Part Name and Function

### Rear View





# SPT-7000

Introduction ▶

System Installation ▼

- Make sure of installation area  
Before connecting peripherals  
Connecting Peripherals  
System On / Off

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure


## System Installation

### 01. Make sure of installation area It is important to be sure the installed place is safe and comfortable like following contents before setup the system.

- Choose a big and solid desk or table to support the weight of this system.
- Lay this system on a stable and flat surface. Do not install on surface of carpet which may cause static electricity. The data of system may be erased or the circuit board may get damaged.
- Secure the enough space surrounding this system to make air ventilation.
- Keep this system away from humidity, dust, direct sunlight and high temperature. Always keep it in a cool area.
- Make sure the power voltage is within safety range and being adjusted properly to the value of 100–240V before connecting the equipment to the power outlet.
- Power outlets are needed for the system, printer and other peripherals respectively.
- Always keep the equipment from strong magnetic or electrical objects.

**Note!** | You can adjust the angle depending on your using environment.  
The possible range of angle is like below picture.

**Caution!** | ▶ Risk of explosion if battery is replaced by an incorrect type.  
Use the same one with the battery in the mainboard.  
▶ Dispose of used batteries according to the instructions.





# SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
• Before connecting  
peripherals  
Connecting Peripherals  
System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

### 02. Before connecting peripherals First remove Interface Cover at the rear of the system.

#### Connecting Peripherals

##### Remove Interface Cover

Pushing the both lock buttons, pull the Interface Cover and remove it.



Caution!

- ▶ Connect peripherals after turning the power off.
- ▶ Please use gloves to prevent injury from the edge of the equipment.



SPT-7000

Introduction

System Installation

- Make sure of installation area  
Before connecting peripherals
- Connecting Peripherals
- Connecting Serial Port Devices such as Barcode Scanner
- Connecting RJ-11 Cash Drawer
- Connecting RJ-45 LAN Cable
- Connecting USB Device
- Connecting PS Module
- Connecting Security / Scanner Module
- Connecting Receipt Printer
- Receipt Printer
- Dismantle the Cover for Customer Displays
- Connecting DVR Card
- Connecting AC Power Cord to the Set Plug
- Cable Management

System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation

03. Connecting Peripherals

Connecting Serial Port Devices such as Barcode Scanner


Connect barcode scanner, serial interface devices, etc. to the serial port. Each serial device has different power specification.  
After checking power spec., refer to the below table.

| Port | 5V  | 12V | RI  |
|------|-----|-----|-----|
| COM1 | Yes | Yes | Yes |
| COM2 | Yes | Yes | Yes |
| COM3 | Yes | Yes | Yes |
| COM4 | Yes | Yes | Yes |



Connecting RJ-11 Cash Drawer

Use RJ-11 port when cash drawer is used.  
Please set up the power after checking power spec. of cash drawer and then referring to the system composition on appendix B.



**Note!** | We recommend you to use Sam4s Cash Drawer because of different cable specifications by each manufacturer.



SPT-7000

Introduction

System Installation

- Make sure of installation area
- Before connecting peripherals
- Connecting Peripherals
  - Connecting Serial Port Devices such as Barcode Scanner
  - Connecting RJ-11 Cash Drawer
  - Connecting RJ-45 LAN Cable
  - Connecting USB Device
  - Connecting PS Module
  - Connecting Security / Scanner Module
  - Connecting Receipt Printer
  - Receipt Printer
  - Dismantle the Cover for Customer Displays
  - Connecting DVR Card
  - Connecting AC Power Cord to the Set Plug
  - Cable Management

System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation

03. Connecting Peripherals

Connecting RJ-45 LAN Cable

RJ-45 LAN or Internet-enabled cable can be connected.  
It supports 10/100/1000Mbps.



Connecting USB Device

USB connector is located at the side of and the back of the system so USB Devices can be connected at the both locations.  
USB hub can be used to connect various USB devices.  
USB devices are like keyboard, mouse, CCD camera, printer and signature pad.  
(According to the type of USB devices, the drivers may be required.)





# SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

## • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
**Connecting PS Module**  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer  
Receipt Printer  
Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure


## System Installation

# 03. Connecting Peripherals

## Connecting PS Module (Option)

In case using MSR, after removing side cover which is located at the right side of LCD, then connect the module.

The module is easily connected as USB connector type.





SPT-7000

Introduction

System Installation

- Make sure of installation area  
Before connecting peripherals
- Connecting Peripherals
  - Connecting Serial Port Devices such as Barcode Scanner
  - Connecting RJ-11 Cash Drawer
  - Connecting RJ-45 LAN Cable
  - Connecting USB Device
  - Connecting PS Module
  - Connecting Security / Scanner Module
  - Connecting Receipt Printer
- Receipt Printer
- Dismantle the Cover for Customer Displays
- Connecting DVR Card
- Connecting AC Power Cord to the Set Plug
- Cable Management
- System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation

03. Connecting Peripherals

Connecting Security/Scanner Module (Option)

In case using Fingerprint / Dallas / Scanner / Smart Card Reader (SCR), after removing the cover which is located at the right bottom and then connect the module.

Please refer to system assembly / disassembly of the System Expansion on how to assemble or disassemble Security / Scanner Module.



Connecting Receipt Printer (Option)

In case using Receipt Printer, after removing the cover which is located at the left bottom and then connect the printer module.

Please refer to system assembly / disassembly of the System Expansion on how to assemble or disassemble receipt printer module.



| Print Status     | Beep Sound  | Status LED                  |
|------------------|---|-----------------------------|
| Normal           | No Sound  | Green Color Led             |
| Cover Open       | No Sound  | Red Color Led               |
| No Paper         | A Long Beep Sound Repeat(Pee — Pee — )              | Cross Lighting(Green ↔ Red) |
| Cutter Jam       | Two times Short Beep Sound(PeePee— PeePee—)         | Cross Lighting(Green ↔ Red) |
| Wrong Positioned | Three times Short Beep Sound(PeePeePee— PeePeePee—) | Cross Lighting(Green ↔ Red) |



## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

### • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer

### Receipt Printer

Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

# 03. Connecting Peripherals

## Receipt Printer

### ▪ Install & Test - Install Partition

58mm printing paper can be used in case of installing partition.

1. Pull the printer cover to open as shown.
2. Insert the partition as shown.
3. Push the partition until it fits into the paper feeding box as shown.
4. Insert your finger to the partition hole and pull it. Disassembly is in reverse order.



Partition Hole for Disassembly



## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

### • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer  
**Receipt Printer**  
Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

# 03. Connecting Peripherals

## Receipt Printer

### ▪ Install & Test - Install and Replace Paper Roll

**Note!** | Make sure to use paper rolls that meet the standard.  
Non-standard paper rolls may cause printer malfunction.

1. Pull and open the printer cover as shown.

**Note!** | Do not open the printer cover while printing.

2. Remove the used paper roll inside if there is.

3. Insert the paper roll as shown.

4. Pull out a small amount paper as shown and close the cover.

5. Tear off the paper as shown.

**Note!** | Strongly push the center of the printer cover for  
the proper paper discharge.





SPT-7000

Introduction

System Installation

- Make sure of installation area
- Before connecting peripherals
- Connecting Peripherals
  - Connecting Serial Port Devices such as Barcode Scanner
  - Connecting RJ-11 Cash Drawer
  - Connecting RJ-45 LAN Cable
  - Connecting USB Device
  - Connecting PS Module
  - Connecting Security / Scanner Module
  - Connecting Receipt Printer
  - Receipt Printer
    - Dismantle the Cover for Customer Displays
    - Connecting DVR Card
    - Connecting AC Power Cord to the Set Plug
    - Cable Management
- System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation  
03. Connecting Peripherals

Receipt Printer


Install & Test - Self-Test

- Self-Test Mode  
Self-Test can check products for defects or disorder.  
The procedure for Self-Test is as follows.
1. Check whether the paper is properly inserted.
  2. Turn the power off.
  3. Pressing the Feed Button, turn the power on and then Self-Test begins.
  4. It prints current firmware version and printer status.
  5. After printing current printer status, it stops after printing the below sentence.  
(Status-showing LED will continuously blink.)

SELF TEST PRINTING.  
PLEASE PRESS PAPER FEED BUTTON

6. To continue printing, press Paper Feed Button.
7. Self-Test automatically ends and cut the paper off after printing following message.

\*\* End Self-Test \*\*





## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

### • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer  
**Receipt Printer**  
Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

# 03. Connecting Peripherals

## Receipt Printer

### ▪ Use Function - Paper Feed Button & LED

#### Paper Feed Button


This button can be disabled by the ESC c 5 command.  
Press the Feed button once to advance paper one line.  
You can also hold the FEED button to feed paper continuously.

#### LED

If the power is turned on normally, the LED shows green light.

If some troubles happen such as paper-out, the LED shows red light.

Please refer to the Trouble Shooting on the page of Troubles and Solutions.





## SPT-7000

Introduction ▶

System Installation ▼

Make sure of installation area  
Before connecting peripherals

### • Connecting Peripherals

Connecting Serial Port Devices such as Barcode Scanner  
 Connecting RJ-11 Cash Drawer  
 Connecting RJ-45 LAN Cable  
 Connecting USB Device  
 Connecting PS Module  
 Connecting Security / Scanner Module  
 Connecting Receipt Printer  
**Receipt Printer**  
 Dismantle the Cover for Customer Displays  
 Connecting DVR Card  
 Connecting AC Power Cord to the Set Plug  
 Cable Management

System On / Off

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

### 03. Connecting Peripherals

#### Receipt Printer

#### ▪ Maintenance

Dust can make a falling-off in printing quality.  
Please clean the printer with following procedure.

- 1) Open the printer cover and remove the paper.
- 2) Wipe out the printer head with cloth dipped in alcohol.
- 3) Wipe out the paper roller with cloth in water.
- 4) Insert the paper and close the cover.



#### Caution!

- ▶ Make sure that the power is off before cleaning the printer.
- ▶ Clean the printer 10 minutes after the power-off because the printer head is very hot.
- ▶ Do not touch the printer thermal head.
- ▶ Be careful that the printer head is not damaged.



SPT-7000

Introduction

System Installation

Make sure of installation area  
Before connecting peripherals

Connecting Peripherals

- Connecting Serial Port Devices such as Barcode Scanner
- Connecting RJ-11 Cash Drawer
- Connecting RJ-45 LAN Cable
- Connecting USB Device
- Connecting PS Module
- Connecting Security / Scanner Module
- Connecting Receipt Printer

Receipt Printer

- Dismantle the Cover for Customer Displays
- Connecting DVR Card
- Connecting AC Power Cord to the Set Plug
- Cable Management

System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation

03. Connecting Peripherals

Receipt Printer

Error Status & Error Resolution - Cover Open & No Paper

The printer beeps the buzzer or continuously the error LED blinks when it enters the ERROR status.


When the cover is not closed completely (Cover Open)

The LED shows red light and turns green when the cover completely closed.

No Paper

The buzzer repeatedly sounds like “Beep --- Beep ---” and LED turns on Green / Red light alternately.

In case of opening the cover, the beep sound disappears. Change the paper roll then clear the error status after some motor feeds.





SPT-7000

Introduction

System Installation

- Make sure of installation area  
Before connecting peripherals
- Connecting Peripherals

- Connecting Serial Port Devices such as Barcode Scanner
- Connecting RJ-11 Cash Drawer
- Connecting RJ-45 LAN Cable
- Connecting USB Device
- Connecting PS Module
- Connecting Security / Scanner Module
- Connecting Receipt Printer
- Receipt Printer
- Dismantle the Cover for Customer Displays
- Connecting DVR Card
- Connecting AC Power Cord to the Set Plug
- Cable Management

System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation

03. Connecting Peripherals


Receipt Printer

Error Status & Error Resolution - Cutter Jam

Cutter Jam

The cutter blade cannot proceed forward normally due to some objects are stuck in the printer inside while operating.  
In this case, the buzzer repeatedly sounds like “Beep Beep —, Beep Beep —” and LED turns on Green / Red light alternately.

To solve this error, please refer to “Error Resolution” page 2-15.



Cutter Jam : LED & Buzzer Status



SPT-7000

Introduction

System Installation

Make sure of installation area  
Before connecting peripherals

Connecting Peripherals

- Connecting Serial Port Devices such as Barcode Scanner
- Connecting RJ-11 Cash Drawer
- Connecting RJ-45 LAN Cable
- Connecting USB Device
- Connecting PS Module
- Connecting Security / Scanner Module
- Connecting Receipt Printer

Receipt Printer

- Dismantle the Cover for Customer Displays
- Connecting DVR Card
- Connecting AC Power Cord to the Set Plug
- Cable Management

System On / Off

System Use

System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

System Installation

03. Connecting Peripherals

Receipt Printer


Error Status & Error Resolution - Cutter Not Home

Cutter Not Home

This happens if the cutter blade steps forward while the printer is on (LED is light on).

In this case, the buzzer repeatedly sounds like “Beep Beep Beep —, Beep Beep Beep —” and LED turns on Green / Red light alternately.

To solve this error, please refer to “Error Resolution” page 2-15.



Cutter Not Home : LED and Buzzer Status



## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

### • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer

#### Receipt Printer

Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

# 03. Connecting Peripherals

## Receipt Printer

### ▪ Error Status & Error Resolution - Error Resolution

#### Cutter Jam / Cutter Not Home

1. Pull the printer cover and open it.
2. In case the cover is not open completely, repeat to open and close the cover 2 or 3 times.  
Then, the cutter takes a step backwards and you can open the cover normally.
3. If the cover opens completely, remove jammed paper and then close the cover.





# SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

## • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer

### Receipt Printer

Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

# 03. Connecting Peripherals


## Receipt Printer

### ▪ Error Status & Error Resolution - Error Resolution



Note!

- ▶ If you cannot solve “Cutter Jam” or “Cutter Not Home” errors by the method mentioned in page 2-15,
- ▶ please dismantle the cover cutter. Then, raise upward the blade knobs using a tool as shown. And open the printer cover.





## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

### • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer  
Receipt Printer  
Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure


## System Installation

### 03. Connecting Peripherals

#### Dismantle the Cover for Customer Displays (Option)

After dismantling the cover, connect CDP / 7" Dual LCD / 15" Dual LCD into the system.

Refer to System Disassembly / Assembly of System Expansion.





## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

### • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer  
Receipt Printer  
Dismantle the Cover  
for Customer Displays  
**Connecting DVR Card**  
Connecting AC Power  
Cord to the Set Plug  
Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

## System Installation

### 03. Connecting Peripherals

#### Connect DVR Card

1. Push the both lock button of the rear cover and then pull the cover as shown.
2. Remove the two screws on the Interface and the bracket.
3. Remove the DVR sheet from the Interface and attach it to the bracket.
4. Assemble Raiser Card and DVR Card and then fit it into PCI slot.
5. Screw it as shown and then assemble the cover.





# SPT-7000

Introduction ▶

System Installation ▼

- Make sure of installation area
- Before connecting peripherals
- Connecting Peripherals
  - Connecting Serial Port Devices such as Barcode Scanner
  - Connecting RJ-11 Cash Drawer
  - Connecting RJ-45 LAN Cable
  - Connecting USB Device
  - Connecting PS Module
  - Connecting Security / Scanner Module
  - Connecting Receipt Printer
  - Receipt Printer
  - Dismantle the Cover for Customer Displays
  - Connecting DVR Card
  - Connecting AC Power Cord to the Set Plug
  - Cable Management
- System On / Off

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Installation

### 03. Connecting Peripherals

#### Connecting AC Power Cord to the Set Plug

1. Push the both lock button as shown and then pull the Interface cover.
2. Connect AC Power Cord to AC Plug on the rear of the set.  
(The adaptor used in this system support free voltage. It can be used both in 100V and 220v.)



**Caution!** | ▶ SPT-7000 Adaptor from Sam4s should be only used.  
▶ Never use the adaptor with similar specification or shape.





# SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals

## • Connecting Peripherals

Connecting Serial Port Devices  
such as Barcode Scanner  
Connecting RJ-11 Cash Drawer  
Connecting RJ-45 LAN Cable  
Connecting USB Device  
Connecting PS Module  
Connecting Security  
/ Scanner Module  
Connecting Receipt Printer  
Receipt Printer  
Dismantle the Cover  
for Customer Displays  
Connecting DVR Card  
Connecting AC Power  
Cord to the Set Plug

Cable Management

System On / Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

## System Installation

# 03. Connecting Peripherals

## Cable Management

1. Manage cables using the Stand Rib and close the Interface cover.



Caution !

▶ Connect peripherals after turning the power off.

▶ Please use gloves to prevent injury from the edge of the equipment.



## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals  
Connecting Peripherals  
• System On / Off

System On  
System Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Installation

## 04. System On / Off

### System On

After installation of the system, proceed to power on the system with following steps.

1. Power up the peripherals which are connected with the system.
2. Press the power button placed at the right bottom side of the system.
3. Power Light is to be lit at the right bottom side of the system.
4. Windows initial screen will appear after a while.





## SPT-7000

Introduction ▶

System Installation ▼

Make sure of  
installation area  
Before connecting  
peripherals  
Connecting Peripherals  
• System On / Off

System On  
System Off

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Installation

## 04. System On / Off

### System Off

1. All application programs should be off after saving files.
2. Press <Start> button and select 'Turn Off Computer' on popup menu.



3. System will be shut down when <Turn Off> is clicked.





SPT-7000

Introduction

System Installation

System Use

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion  
& Dismantle

Appendix A  
System Set-Up



Appendix B  
System Structure

System Use

01. Keyboard

Using Key board is used for inputting data, it consists of letter keys, number keys, and special keys.  
Keyboard function is depends on the model type the customer purchase. If you want to use PS/2 keyboard type, please connect keyboard when the system powered off.

- Using Keyboard is used for inputting data, it consists of letter keys, number keys, and special keys.

| Key   | Instructions  |
|---|---|
| Tab   | When you press one time, a cursor moves right. When you press shift and tab key at same time, a cursor moves left.  |
| Caps Lock   | When you press this key. Caps Lock LED is turned on. In this state, you can write upper case.<br>If you press this key again, you can write lowercase.  |
| Shift   | If using this with character or number key, you can input the upper small characters of key. In case of English character, you can use uppercase.   |
| Ctrl  | Execute special functions with other keys.  |
| Alt   | Execute character code or functions with other keys.  |
| Backspace   | Delete the left character and move left.  |
| Enter   | If you want to execute command, you press this key at the end of command line.  |
| Insert  | Set 'On' nor 'Off' in insert mode.  |
| Delete  | Delete the character at which cursor is currently located.  |
| Home, End, PgUp, PgDn, ↑, ↓, ←, →   | You can move cursor, when using application.<br>You can move cursor up, down, left, right With ' ↑, ↓, ←, → ' keys.   |
| Num Lock  | Num Lock is a key on the numeric keypad of most computer keyboards, used to switch the pad between number entry and arrow keys.<br>It is a toggle key, like C맨 Lock and Scroll Lock. Its state is commonly represented by an LED light built into the keyboard. |
| F1 – F12  | Do special functions in applications.   |
| Print Screen  | Make the current screenshot. When using with Alt key, only activated window will be captured.   |
|  | Show 'Start' menus  |
|  | Show popup menu such as clicking right button od mouse at which cursor isn currently located.   |

※ Caps Lock, Num Lock, Scroll Lock keys are toggle keys. When you press the key, function is activated. And press again, function is inactivated. When function is activated, light of each LED is on.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

Keyboard Use  
• Touch screen Use  
About POS Driver and Utility  
Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure


### System Use

## 02. Touch Screen Use

Recalibrate if it is not accurate on touch points.




- To recalibrate the touch screen, please follow the procedure blow.

1. Click the right button of mouse on 'elo' icon of Windows tray icons. And select 'Align...' tab on the menu.



2. If the following screen appears, touch the center of red circle for 2 seconds and then unhand from the red point. Repeat the procedure if the red circle appears again.

**Caution!** | Ball point pen or sharpness tools may damage to surface of touch screen.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Use

## 02. Touch Screen Use

Recalibrate if it is not accurate on touch points.

3. If the recalibration is finished, click the green check button and end the recalibration program.



Note!

Recalibration is no need in case for setting up as Extended Screen Mode after connecting Dual Monitor.  
On contrary, recalibration is also no need in case of being changed into Single Screen Mode (LVDS only) while using Extended Screen Mode.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver & Utility
- Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up



Appendix B  
System Structure

### System Use

## 03. About POS Driver & Utility

### POS Driver and Utility

POS Driver & Other utilities are in 'Util\_Driver' folder of C driver.





SPT-7000

Introduction

System Installation

System Use

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion & Dismantle

Appendix A  
System Set-Up



Appendix B  
System Structure

System Use

03. About POS Driver & Utility

POS Driver and Utility

POS Driver & Other utilities are in 'Util\_Driver' folder of C driver.





# SPT–7000

Introduction

▶

System Installation

▶

System Use

▼

- Keyboard Use  
 Touch screen Use  
 • About POS Driver and Utility  
 Dual Monitor Use

System Expansion  
& Dismantle

▶

Appendix A

System Set–Up

Appendix B

System Structure

## System Use

# 03. About POS Driver & Utility

## POS Driver and Utility

OPOS or OLE Retail POS consists of an architecture for win32-based POS device access.  
 The current OPOS driver has been developed in accordance with OPOS Specification Version 1.10 and continues to support the OPOS version.

- Support OS : WEPOS, Win XP Pro, POSReady 2009, POSReady 7, Win 7 Pro, Win 7 Ult

### ▪ Support Peripherals

- LineDisplay : Q202LD
- Cash Drawer : S7000CD
- POSPrinter : ELLIX Series

### ▪ The location of installation file

- The file is shipped on the hard disk  
 (C:₩Util\_Driver₩Utility₩Pos Utility₩OPOS)

### ▪ The way of Installation

- Execute ‘SAM4SOPOSSelr\_Vx.xx.exe’ file in OPOS folder.
- All components will be automatically registered & set up according to the system configuration.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

The system supports 'dual monitors' that is using two monitors for one system. Sub-monitor can be displayed a screen copied a main-monitor's Windows desktop or can be display a screen extended Windows desktop.

1. Connect to external monitor when the system is turned off.  
(If 'connector protecting cover' is removed from the bottom of system, VGA connector is shown.)

- ① Connect to external monitor when the system is turned off.
- ② Connect a power cable to external monitor.

2. Press a power button of the system and the external monitor.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

Keyboard Use  
 Touch screen Use  
 About POS Driver and Utility  
 • Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

3. Click the right button of mouse on Windows desktop screen, and select 'Screen resolution' from a popup menu.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

- On 'Change the appearance of your display' dialog, the 'Display' option is set as '1|2 Multiple Monitors' and 'Multiple displays' option is set as 'Duplicate these displays'.  
(In this case, the dual monitor shows a duplicated screen.)





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

5. If you want to change to an extended screen, set 'Multiple displays' option as 'Extend these displays' on 'Change the appearance of your display' dialog.





# SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion & Dismantle ▶


Appendix A  
System Set-Up

Appendix B  
System Structure

## System Use

### 04. Dual Monitor Use Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

- Set 'Display' option as '1. Digital Flat Panel (1024x768 60 Hz)' and click 'Apply' button.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

7. Select 'Keep changes' button on 'Display Settings' dialog to keep the current settings.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

7. If the configuration is finished, click 'OK' button to close the 'Change the appearance of your displays' dialog.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▼

- Keyboard Use
- Touch screen Use
- About POS Driver and Utility
- Dual Monitor Use

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Use

## 04. Dual Monitor Use

Additional monitor can be connected to the VGA connector. This contents is written based on Windows 7 OS.

**Note!** | ▶ How to check dual monitor's settings  
If 'dual monitors' doesn't work properly, refer to the following procedure.

- **Method 1** Check the System Setup  
Make sure that 'Chipset > Host Bridge > Intel IGD Configuration > Boot Display Device' menu is selected as 'D-SUB + LVDS'
- **Method 2** Click the right button of mouse on 'Intel Graphic icon' of Windows tray area and select 'Graphic Properties' menu.  
Make sure that 'Operating Mode' of 'Multiple Displays' is set as 'Extended Desktop'.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### System Dismantling

1. Press the lock button then, pull "I/F cover" toward the arrow direction & take it from the body.
2. Plug the AC power cord into AC socket in the back side of the body.  
(The adaptor is compatible with 100V & 220V both.)





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### Customer Display Assembling & Dismantling (CDP)

1. Press the lock button then, pull "I/F cover" toward the arrow direction like the pictures to take it from the body.



2. Take the upper cover from the body them remove the dummy cover .



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### Customer Display Assembling & Dismantling (CDP)

3. Equip the body with Customer Display with the cable.



4. Assemble the covers in reverse order.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

### • System Dismantling & Assembling

- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Expansion & Dismantle

# 01. System Dismantling & Assembling

## Customer Display Assembling & Dismantling (DUAL 7" )

1. Press the lock button then, pull "I/F cover" toward the arrow direction like the pictures to take it from the body.



2. Take the upper cover from the body then remove the dummy cover .



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### Customer Display Assembling & Dismantling (DUAL 7" )

3. Clamp a hook for the cable to the body with screw. Put the cable inside of the hook after equipping the system with the Customer display (7")



4. Assemble the covers in reverse order.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### Customer Display Assembling & Dismantling (DUAL 15" )

1. Press the lock button then, pull the cover toward the arrow direction to take it from the body.



2. Take the upper cover from the body then remove the dummy cover .



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### Customer Display Assembling & Dismantling (DUAL 15" )

3. Clamp a hook for the cable to the body with screw. Put the cable inside of the hook after equipping the system with the Customer display (15" )



4. Assemble the covers in reverse order tightening 4 screws.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### SMPS Replacement with DUAL Monitor (15")


1. Lay down the body with care.



2. Remove the power supply cord.

Untighten the hand screw & remove the cover.

3. Disconnect SMPS ASSY from the body.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
  - HDD Replacement
  - Internal Speaker & USB Removal
  - Receipt Printer & Board Removal
  - Scanner & Dallas Removal
  - SMPS Removal
  - Mainboard ASSY Removal
  - Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 01. System Dismantling & Assembling

### SMPS Replacement with DUAL Monitor (15")



4. Remove a screw on the top and the bracket top from the body.



5. Push the connector hook in the front to remove 60W Power.

6. Remove the PAD for 60W & install the one for 80W.

7. Put 80W Power & assemble them in reverse order.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

System Dismantling & Assembling

• HDD Replacement

Internal Speaker & USB Removal

Receipt Printer & Board Removal

Scanner & Dallas Removal

SMPS Removal

Mainboard ASSY Removal

Various Boards Removal

Main Memory Removal

Remove Display Assembly

Remove MSR

Remove Display Board

Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle



## 02. HDD Replacement

You can only use 2.5 inch SATA type HDD for the system.

1. Make sure the system is off for the replacement.
2. Push up the display & press 'PUSH' button on the front cover to push leftward & remove the cover



3. Remove the hand screw & push the bracket rightward to unlock it. Then, take it out upwards & remove the cable.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

System Dismantling & Assembling

• HDD Replacement

Internal Speaker & USB Removal

Receipt Printer & Board Removal

Scanner & Dallas Removal

SMPS Removal

Mainboard ASSY Removal

Various Boards Removal

Main Memory Removal

Remove Display Assembly

Remove MSR

Remove Display Board

Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 02. HDD Replacement

You can only use 2.5 inch SATA type HDD for the system.

4. Remove the bracket from the HDD.



5. Remove hand screws (4ea) from the HDD.



6. Assemble a new HDD in reverse order & connect the cable.

7. Turn on the system & check the HDD are installed properly with System Set up chapter in appendix A.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion &amp; Dismantle ▼

System Dismantling  
& Assembling

HDD Replacement

• Internal Speaker  
& USB RemovalReceipt Printer  
& Board RemovalScanner  
& Dallas Removal

SMPS Removal

Mainboard ASSY Removal

Various Boards Removal

Main Memory Removal

Remove Display Assembly

Remove MSR

Remove Display Board

Remove Touch Panel &amp; LCD



## System Expansion &amp; Dismantle

## 03. Internal Speaker &amp; USB Removal

1. Turn off the system.
2. Push up the display & push the cover speaker to the right to remove it from the body.



3. Remove a screw to remove the speaker cover.  
Remove a screw to take out the USB board.

Appendix A  
System Set-UpAppendix B  
System Structure



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle



## 04. Receipt Printer & Board Removal

### Receipt Printer & Board Removal

1. Turn off the system before the receipt printer removal.
2. Push up the display & take out the cover cutter with grip. Then, open the cover printer.



3. Lift up the lock lever inside & pull the printer towards outside to remove it from the body.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 04. Receipt Printer & Board Removal

### Receipt Printer & Board Removal

4. Assemble the dummy printer, when it does not apply the receipt printer.  
Hang the hook of the dummy printer & push it upwards.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 04. Receipt Printer & Board Removal

### Receipt Printer Assembling

1. Assemble in reverse order. Join the connector then tilt the printer at an angle of 15 degrees, then push in the upper side of printer first, then push in the printer cover. The printer is assembled automatically.  
(Pull the printer cover back and forth in order to check the printer is well assembled.)
2. Equip the right side of cutter cover first, then push the left side to assemble.
3. Turn on the printer power, then check printer is well assembled.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 04. Receipt Printer & Board Removal


### Printer Board Removal

1. Remove screws(2) to remove the printer board.



### Printer OSD Board Removal

1. Remove screws(2) to take the cover away
2. Unscrew a screw to remove the OSD board.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

System Dismantling & Assembling  
HDD Replacement  
Internal Speaker & USB Removal  
Receipt Printer & Board Removal  
• Scanner & Dallas Removal  
SMPS Removal  
Mainboard ASSY Removal  
Various Boards Removal  
Main Memory Removal  
Remove Display Assembly  
Remove MSR  
Remove Display Board  
Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 05. Scanner & Dallas Option Removal

### Scanner & Dallas Removal

1. Turn off the system.
2. Push up the display.  
Slide the button on the cover to the right to unlock & pull it towards outside to remove.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 05. Scanner & Dallas Option Removal

### Scanner & Dallas Removal

1. Assemble the dummy printer, when it does not apply Scanner / Dallas options.



### Scanner & Dallas Assembling

- Assemble Scanner & Dallas in reverse order & check if they are installed properly.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▶

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle


## 05. Scanner & Dallas Option Removal

### HUB board & IC card Removal

1. Remove screws(2) to remove the HUB board
2. Remove screws(2) to remove IC card.

### Scanner & Dallas / FPR Removal

1. Remove screws(2) to remove the Scanner.
2. Remove screws(1) to remove the Dallas / FPR.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 05. Scanner & Dallas Option Removal


### OSD board Removal

1. Unscrew screws(2) & remove the scanner bracket.
2. Unscrew screw(1) & remove the bracket.
3. Unscrew screws(2) & remove the OSD board.



### OSD board on the dummy cover Removal

1. Unscrew screws(2) & remove the bracket.
2. Unscrew screws(2) & remove the OSD board.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- **SMPS Removal**
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

## System Expansion & Dismantle


### 06. SMPS Removal

#### SMPS Removal

1. Turn off the system.
2. Lay the system down with care to protect the LCD panel.



3. Remove the power cord.  
Remove the hand screw & push up the bracket handle to unlock.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 06. SMPS Removal

### SMPS Removal

4. Pull the bracket handle towards you to remove the SMPS.



### SMPS Assembling

Assemble the SMPS in reverse order & check if it is installed properly.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 07. Mainboard ASSY Removal

### Mainboard ASSY Removal

1. Turn off the system.  
※ Power & other cables must be removed before dismantling the system.
2. Refer to System Dismantle section to remove Interface & rear cover.

3. Slide the top cover to the left & remove the screw to remove another cover.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 07. Mainboard ASSY Removal

### Mainboard ASSY Removal

4. Remove harness & unscrew the screws(2) in both sides.
  5. Hold the I / F bracket & push it up to unlock. Then, remove it.
- Note. Handle them with care for harness.



### Mainboard ASSY Assembling

Assemble it in reverse order & check if it is installed properly.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 08. Various Boards Removal


### CFAST Board Removal

1. Remove the screws(2) to remove CFAST board.



### Main Board Removal

1. Remove 4 screws to remove Main board.





SPT-7000

- Introduction
- System Installation
- System Use

System Expansion & Dismantle


- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

- Appendix A  
System Set-Up
- Appendix B  
System Structure

System Expansion & Dismantle  
08. Various Boards Removal


Parallel Board Removal

1. Remove 4 screws to remove Parallel board.



Drawer Board Removal

1. Remove 2 screws to remove the drawer board.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
  - Main Memory Removal
  - Remove Display Assembly
  - Remove MSR
  - Remove Display Board
  - Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 08. Various Boards Removal


### VFD Board Removal

1. Refer to the pictures.
2. Remove a screw to remove VFD board.



### Power Board Removal

1. Refer to the pictures.
2. Remove a screw to remove Power board.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 08. Various Boards Removal

### WIFI Board Removal

1. Remove the front cover like the first picture.
2. Push up the covers in both sides to remove.
3. Remove the screws(6) on the top & the cross assy.
4. Remove a screw to remove the WIFI board.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle ▼

System Dismantling  
& Assembling  
HDD Replacement  
Internal Speaker  
& USB Removal  
Receipt Printer  
& Board Removal  
Scanner  
& Dallas Removal  
SMPS Removal  
Mainboard ASSY Removal  
Various Boards Removal

- Main Memory Removal

Remove Display Assembly  
Remove MSR  
Remove Display Board  
Remove Touch Panel & LCD

Appendix A  
System Set-UpAppendix B  
System Structure

## System Expansion &amp; Dismantle

## 09. Main Memory Removal

## Main Memory Removal

You might need to extend the memory capacity.

You need to check the specification of the main & extended memory when you extend the main memory.

Memory supports max. 4GB according to the board specification.

BIOS will automatically detect memory type, size & speed, when the new one is equipped.

1. Turn off the system.


※ All cables must be disconnected before dismantling of the system.

2. Remove I/F & rear covers.

3. Push the top cover to remove.

Then, remove a screw & push the dummy cover to the upper side.

4. Pull the levers in both sides to remove the memory.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

System Dismantling & Assembling  
HDD Replacement  
Internal Speaker & USB Removal  
Receipt Printer & Board Removal  
Scanner & Dallas Removal  
SMPS Removal  
Mainboard ASSY Removal  
Various Boards Removal  
Main Memory Removal  
• Remove Display Removal  
Remove MSR  
Remove Display Board  
Remove Touch Panel & LCD

Appendix A  
System Set-Up



Appendix B  
System Structure

### System Expansion & Dismantle

## 10. Remove Display Assembly

### Remove Display Assembly

1. Turn off the system.  
※ Remove cables for power before disassembly.
2. Dismantle Interface Cover and Rear Cover.  
If a Dual Monitor is installed, disconnect cables and remove the Dual Monitor.  
Unscrew cable harness and remove it.
3. Remove 4 harness for display.  
(TOUCH,MSR,LVDS,INVERTER)
4. Unscrew 2 screws at the back side after lifting display and disassemble.  
(Be careful not to cut off harness.)



### Assembly of Display

Assemble in retrograde order and check the display is correctly assembled.



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up

Appendix B  
System Structure

### System Expansion & Dismantle

## 11. Remove MSR


### Disassembly of MSR

1. Unscrew a screw. Push to the left and disassemble it.

### Assembly of MSR

1. Assemble in reverse order and tighten the screw.

In case not using MSR, push the Dummy Cover to the right to assemble.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 12. Remove Display Board

### Remove Display Board (Inverter, MSR, Touch)

1. Unscrew a screw by hand and disassemble by moving Cover Top (Up) and Cover Bottom (Down).





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▼

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD

Appendix A  
System Set-Up


Appendix B  
System Structure

### System Expansion & Dismantle

## 12. Remove Display Board


### Remove Inverter

1. Remove all the connected harness.
2. Unscrew 2 screws and disconnect Inverter.




### Remove MSR Board

1. Remove all the connected harness.
2. Unscrew 2 screws and disconnect MSR Board.



### Remove Touch Board

1. Remove all the connected harness.  
Handle the Touch Cable very carefully.
2. Unscrew 3 screws and disconnect Touch Board.





SPT-7000

- Introduction
- System Installation
- System Use

System Expansion & Dismantle

- System Dismantling & Assembling
- HDD Replacement
- Internal Speaker & USB Removal
- Receipt Printer & Board Removal
- Scanner & Dallas Removal
- SMPS Removal
- Mainboard ASSY Removal
- Various Boards Removal
- Main Memory Removal
- Remove Display Assembly
- Remove MSR
- Remove Display Board
- Remove Touch Panel & LCD



- Appendix A  
System Set-Up
- Appendix B  
System Structure

System Expansion & Dismantle  
13. Remove Touch Panel & LCD

Remove Touch Panel & LCD

**Caution!** | It may happen defectives while disconnecting LCD and Touch Panel due to dust or mishandling.


- 1. Remove Touch Cable with care.
- 2. Unscrew 12 screws and disassemble the Bracket.



- 3. Unscrew 4 screws from disassembled Bracket Assembly and Remove LCD.

Assembly of Touch Panel and LCD

Assemble them in reverse order and check the position of Bracket and LCD.





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up

- System Set-up Preview
  - Main Menu
  - Advanced Menu
  - Chipset Menu
  - Boot Menu
  - Security Menu
  - Save & Exit Menu

Appendix B  
System Structure

### BIOS Set-up

## 01. BIOS Set-up Preview

Set-up means that the system configuration information is memorized on ‘BIOS’.  
The set-up data is saved in a special area of memory called CMOS ROM.

BIOS (Basic Input and Output System) Set-up is menu-oriented software utility which enables a user to configure the system’s environmental set-up, hardware installed to the system, power saving function and so on. BIOS Set-up values can seriously affect on how the system works. Therefore, users should figure out all the options regarding BIOS Set-up and it is very important to set up the system according to user’s working environment.

### Entering the Setup

- Turn on the system and the system will show ‘Press <DEL> to enter SETUP’ message.  
When this message show up, press <DEL> or <Delete> key to enter SETUP screen.

### Cases of BIOS Setup

- When checking HDD type and capacity after HDD replacement
- When changing booting sequence
- When reflecting user’s need on the setup
- When setting or changing a password



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up

- System Set-up Preview
  - Main Menu
  - Advanced Menu
  - Chipset Menu
  - Boot Menu
  - Security Menu
  - Save & Exit Menu

Appendix B  
System Structure


BIOS Set-up

01. System Set-up Preview

Set-up means that the system configuration information is memorized on 'BIOS'.  
The set-up data is saved in a special area of memory called CMOS ROM.


Initial Setup Screen

- Initial Setup Screen has such menus Main, Advanced, Chipset, Boot, Security, Save & Exit.



Using Keys on Setup Screen

- Press 'F1' key to see simple explanations on key functions.





SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up ▼

- System Set-up Preview
  - Main Menu
  - Advanced Menu
  - Chipset Menu
  - Boot Menu
  - Security Menu
  - Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

01. System Set-up Preview

Set-up means that the system configuration information is memorized on ‘BIOS’.  
The set-up data is saved in a special area of memory called CMOS ROM.

- →← : Move  
Move the cursor to select a screen.
- ↑ ↓ : Move  
Move the cursor to select a menu or option tab. The color of selected menu will be changed to White.
- Enter : Select  
Some of menus include sub-menus. You can select sub-menu by clicking <Enter> key.
- +- : Value  
Use them for setting value.
- ESC : Exit  
Exit setup program without saving changes.
- F1 : General Help  
Shows a list of keys used in System Setup.
- F9 : Load Optimal Defaults  
Load default configuration values which the mainboard manufacturer set up.
- F10 : Save and Exit  
Save changed values and exit setup program.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
  - Advanced Menu
  - Chipset Menu
  - Boot Menu
  - Security Menu
  - Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

02. Main Menu

Use this menu for basic system setup such as time, date and etc. and system information.



System Date

If needed, set up the date on ‘System Date’.  
The date format is <Month> <Day> <Year> in order. Move to the item with <Tab> or <Enter> key and change it with <+>, <Space> or <-> key.

System Time

If needed, set up the time on ‘System Time’.  
The time format is <Hour> <Minute> <Second> in order. Move to the item with <Tab> or <Enter> key and change it with <+>, <Space> or <-> key.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Launch Storage OpROM

This item allows you to enable or disable Boot Option for Legacy Mass Storage Devices with Option ROM.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced > PCI Subsystem Settings

- PCI ROM Priority

In case of multiple option ROMs (Legacy and EFI Compatible), this item specifies what PCI Option ROM to launch.
- PCI Latency Timer

This item sets the value to be programmed into PCI Latency Timer Register.
- VGA Palette Snoop

This item enables or disables VGA Palette Registers Snooping.
- PERR# Generation

This item enables or disables PCI Device to generate PERR#.
- SERR# Generation

This item enables or disables PCI Device to generate SERR#.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced > ACPI Settings

- Enable ACPI Auto Configuration
- Enable Hibernation
- ACPI Sleep State
- Lock Legacy Resources
- S3 Video Repost
- PME Wake up from S5
- Wake system with Fixed Time
- Wake up date / Wake up hour / Wake up minute / Wake up second
- EuP Control
- Ring-In Wake up from S5
- USB Device Wake up from S3/S4

The item enables or disables BIOS ACPI Auto Configuration.

The item enables or disables System ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

This item selects the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.

This item enables or disables Lock of Legacy.

The item enables or disables S3 Video repost.

The item enables the system to wake from S5 using PME event.

This item enables or disables the system to wake on by alarm event. When this item is enabled, the system will wake on the hr::min::sec specified.

Sets up specific time and date that the system will wake up.

When EuP is enabled, the system will meet EuP requirement.

This item enables the system to wake from S5 using Ring-In event.

This item enables the system to wake from S3/S4 using USB device.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- **Advanced Menu**
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced > CPU Configuration

- **Hyper Threading Technology**

Enabled for Windows XP and Linux (OS optimized for Hyper Threading Technology) and disabled for other OS (OS not optimized for Hyper Threading Technology).
- **Execute Disable Bit**

This item allows you to configure the Execute Disabled Bit function, which protects your system from buffer overflow attacks.
- **Limit CPUID Maximum**

When the computer is booted up, the operating system executes the CPUID instruction to identify the processor and its capabilities. Before it can do so, it must first query the processor to find out the highest input value CPUID recognizes. This determines the kind of basic information CPUID can provide the operating system.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced › SATA Configuration

- SATA Controller(s)

This item enables/disables Serial ATA Controller (s).
- Configure SATA as

This item selects a configuration for SATA controller.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced › Intel Fast Flash Standby

- |                                     |   |
|-------------------------------------|---|
| ▪ iFFS Support                      | This item enables or disables iFFS.         |
| ▪ Entry on S3 RTC Wake              | iFFS invocation upon S3 RTC.                |
| ▪ Entry After                       | Enable RTC wake timer as S3 entry.          |
| ▪ Entry on S3 Critical Battery Wake | iFFS invocation upon critical battery wake. |



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- **Advanced Menu**
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced › USB Configuration

- **Legacy USB Support**

This item determines if the BIOS should provide legacy support for USB devices like the keyboard, mouse, and USB drive. This is a useful feature when using such USB devices with operating systems that do not natively support USB (e.g. Microsoft DOS or Windows NT).
- **EHCI Hand-Off**

This is a workaround for OSes without EHCI hand-off support. The EHCI ownership change should be claimed by EHCI driver.
- **USB transfer time-out**

The time-out value is for Control, Bulk, and Interrupt transfers.
- **Device reset time-out**

This is the USB mass storage device Start Unit command time-out.
- **Device power-up delay**

This is maximum time for the device to take before it properly reports itself to the Host Controller.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced › Super IO Configuration

- Serial Port 5/6 Configuration

Decides to use Serial Port 5/6 and sets up IRQ and IO Address.
- Parallel Port Configuration

Decides to use Parallel Port and sets up IRQ, IO Address, Device Mode, etc.
- Restore AC Power Loss by IO

This setting specifies how your system should behave after a power fail or interrupts occurs.

– Power Off: Leaving the system in power-off status after power recovers.

– Power ON: Powering on the system immediately when power returns.

– Last State: 1. Leaving the system in power-off if the system shuts down at DC off status;  
2. Powering on the system immediately if the system shuts down at DC on status.
- Watch Dog Degree

This item allows you to determine the functional degree of Watch Dog.
- Watch Dog Timer

Sets up the time of Watch Dog Timer function.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced › H/W Monitor

- CPU Temperature

Shows current temperature of CPU.
- System Temperature

Shows current temperature of System.
- CPU VCore

Shows current voltage of CPU.
- DRAM Voltage

Shows current voltage of DRAM.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



Advanced › F81216 Second Super IO Configuration

- Serial Port 1/2/3/4 Congifuration

Decides to use Serial Port 1/2/3/4 and sets up IRQ and IO Address.
- UART IRQ Mode

This item allows you to select PCI IRQ Sharing for QS(Ex. Windows) and ISA IRQ for DOS.



# SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

## BIOS Set-up

### 03. Advanced Menu

Use this menu for basic system setup such as time, date and etc. and system information.



#### Advanced › GPIO Control

- Audio AMP output

This item allows you to select Audio AMP output dB value.
- Panel Backlight Voltage

This item allows you to select Panel Backlight voltage.
- Serial Port 1/2/4 PIN9 type

This item allows you to select Serial port pin 9 type is Ring, Vcc 5V, Vcc 12V.
- Serial Port 3 PIN2 type

This item allows you to select Serial port pin 2 type is Ring, Vcc 5V, Vcc 12V.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure


BIOS Set-up

04. Chipset Menus

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components.



Chipset › Host Bridge





SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

04. Chipset Menus

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components.



Chipset › Host Bridge › Memory Frequency and Timing

- MRC Fast Boot

This item enables or disables MRC fast boot.
- Max TOLUD

This item sets maximum value of TOLUD. Dynamic assignment would adjust TOLUD automatically based on largest MMIO length of installed graphic controller.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

04. Chipset Menus

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components.



Chipset › Host Bridge › Intel IGD Configuration

- Boot Display Device

This item selects the video device which will be activated during POST. This has no effect if external graphics present.
- LCD Panel Type

This item selects the LCD panel used by Internal Graphics Device by selecting the appropriate setup item.
- Panel Scaling

This item selects the LCD panel scaling option used by the Internal Graphics Device.
- Active LVDS

This item selects the Active LVDS Configuration.
- Fixed Graphics Memory Size

This item configures the Fixed Graphics Memory Size.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

04. Chipset Menus

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components.



Chipset › South Bridge

- |                               |   |
|-------------------------------|---|
| ▪ Onboard PCIE LAN1           | This item enables or disables Onboard PCIE LAN1.  |
| ▪ Onboard PCIE LAN1 OpROM     | This item enables or disables the Boot Option for Legacy Network Devices.   |
| ▪ DMI Link ASPM Control       | This item enables or disables the control of Active State Power Management on both NB and SB sides of the DMI Link. |
| ▪ PCI-Exp. High Priority Port | This item selects a PCI Express High Priority Port.   |
| ▪ High Precision Timer        | This item enables or disables the High Precision Event Timer.   |
| ▪ SLP_S4 Assertion Width      | This item selects a minimum assertion width of the SLP_S4# signal.  |



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

04. Chipset Menus

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components.



Chipset › South Bridge › TPT Device

- Azalia Controller

You can use this item to select the Azalia Controller.
- Azalia PME Enable

You can use this item to enable or disable Power Management capability of Audio Controller.
- Azalia Vci Enable

Azalia supports 1 extended VC, which will override ICH VCp settings when enabled.
- Select USB Mode

This item selects USB mode to control USB ports.
- UHCI#1 (ports 0 and 1) / UHCI #2 (ports 2 and 3) / UHCI #3 (ports 4 and 5) / UHCI #4 (ports 6 and 7)

You can use these items to control USB UHCI (USB 1.1) function, but disable the controllers from highest to lowest.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

04. Chipset Menus

This section describes configuring the PCI bus system. PCI, or Personal Computer Interconnect, is a system which allows I/O devices to operate at speeds nearing the speed of the CPU itself uses when communicating with its own special components.



Chipset › South Bridge › TPT Device

- USB Function

Sets up the number of USB Ports.
- USB 2.0 (EHCI) Support

You can use this item to enable or disable USB 2.0 (EHCI) Support.
- SMBus Controller

You can use this item to enable or disable OnChip SMBus Controller.
- SIRQ Logic

You can use this item to enable or disable SIRQ logic.
- SIRQ Mode

You can use this item to set SIRQ mode.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle


Appendix A  
System Set-Up

- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

05. Boot Menu Use this menus to specify the system boot option.



- Setup Prompt Timeout

You can use this item to set the number of seconds waiting for setup activation key.
- Bootup Num-Lock State

You can use this item to select the keyboard NumLock State after the system has been switched on.
- Full Screen LOGO Display

This item allows you to enable or disable Full Screen LOGO Show function.
- GateA20 Active

UPON REQUEST - GA20 can be disabled using BIOS services. ALWAYS - it doesn't allow disabling the GA20; this option is useful when any RT code is executed above 1MB.
- Option ROM Messages

This item can set the display mode for Option ROM.
- Interrupt 19 Capture

Interrupt 19 is the software interrupt that handles the boot disk function. When this item is set to Enabled, it allows the Option ROMs to trap Interrupt 19.
- Boot Success Beep

When this item is set to Enabled, BIOS will let user know boot success with beep.
- UEFI Boot

This item enables or disables boot from the UEFI Devices.
- Boot Option Priorities

Items in this sub-menu specify the boot device priority sequence from the available devices. The number of device items that appears on the screen depends on the number of devices installed in the system.
- Hard Disk Drive BBS Priorities

The BIOS will attempt to arrange the hard disk boot sequence automatically. You can also change the booting sequence. The number of device items that appears on the screen depends on the number of devices installed in the system.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

06. Security Menu

This menu allows you to provide/revise supervisor and user password.



- **Administrator Password** This item sets Administrator Password.
- **User Password** This item sets User Password.



SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle

Appendix A  
System Set-Up


- System Set-up Preview
- Main Menu
- Advanced Menu
- Chipset Menu
- Boot Menu
- Security Menu
- Save & Exit Menu

Appendix B  
System Structure

BIOS Set-up

07. Save & Exit Menu

This menu allows you to load the optimal default settings, and save or discard the changes to the BIOS items.



- |                            |   |
|----------------------------|---|
| ▪ Discard Changes and Exit | Abandon all changes made during the current session and exit setup.   |
| ▪ Save Changes and Reset   | Reset the system after saving the changes.  |
| ▪ Restore Defaults         | This selection allows you to reload the BIOS when problem occurs during system booting sequence. These configurations are factory settings optimized for this system. |
| ▪ Boot Override            | This item allows you to exit the system setup without saving any changes.   |



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure


- System Block
- Mainboard Overview
- Exploded View

### System Structure

## 01. System Block

### System Block Diagram

- EIC10-SAM(D2550)





## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure ▼

System Block  
• Mainboard Overview  
Exploded View

### System Structure

## 02. Mainboard Overview

### Main Chipset & Connector





# SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion & Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

## System Structure

## 02. Mainboard Overview

### Main Jumper Setting



BIOS Clear Jumper(JCOMS1)

| Jumper Setting | Voltage                   |
|----------------|---------------------------|
| 1 – 2 Short    | Normal Operation(Default) |
| 2 – 3 Short    | CMOS Clear                |



Serial(JPC5/6) Voltage Jumper  
– Serial5(JPC5)

| Jumper Setting | Voltage      |
|----------------|--------------|
| 1 – 2 Short    | RI           |
| 3 – 4 Short    | 5V (Default) |
| 5 – 6 Short    | 12V          |


– Serial6(JPC6)

| Jumper Setting | Voltage       |
|----------------|---------------|
| 1 – 2 Short    | RI            |
| 3 – 4 Short    | 5V            |
| 5 – 6 Short    | 12V (Default) |



Inverter Voltage Jumper(JLV2)

| Jumper Setting | Voltage       |
|----------------|---------------|
| 1 – 2 Short    | 5V            |
| 2 – 3 Short    | 12V (Default) |





SPT-7000

Introduction

System Installation

System Use

System Expansion  
& Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
02. Mainboard Overview

Parallel Communication Port (D-SUB25 Female)



Parallel Port (D-SUB25 Female)

| Pin Num | SPP     | ECP                 | EPP      | In/Out |
|---------|---------|---------------------|----------|--------|
| 1       | /STROBE | /STROBE             | /WRITE   | I/O    |
| 2       | PD0     | PD0                 | PD0      | I/O    |
| 3       | PD1     | PD1                 | PD1      | I/O    |
| 4       | PD2     | PD2                 | PD2      | I/O    |
| 5       | PD3     | PD3                 | PD3      | I/O    |
| 6       | PD4     | PD4                 | PD4      | I/O    |
| 7       | PD5     | PD5                 | PD5      | I/O    |
| 8       | PD6     | PD6                 | PD6      | I/O    |
| 9       | PD7     | PD7                 | PD7      | I/O    |
| 10      | /ACK    | /ACK                | NTR      | I      |
| 11      | BUSY    | /BUSY,PERIPHACK     | /WAIT    | I      |
| 12      | PERROR  | PE,/ACKREVERSE      | PE       | I      |
| 13      | SELECT  | SELECT              | SELECT   | I      |
| 14      | /AUTOFD | /AUTOFD,HOSTACK     | /DATASTB | O      |
| 15      | /FAULT  | /FAULT,/PERIPHREQST | /FAULT   | I      |
| 16      | /INIT   | /FAULT,/REVERSEQST  | /RESET   | O      |
| 17      | /SLCTIN | /SLCTIN             | /ADDRSTB | O      |
| 18-25   | GND     | GND                 | GND      | -      |



SPT-7000

- Introduction ▶
- System Installation ▶
- System Use ▶
- System Expansion & Dismantle ▶

Appendix A  
System Set-Up


Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure

# 02. Mainboard Overview

Serial Communication Port (D-SUB9 Male/RJ45)



▪ COM1/2/4(DSUB9 MALE)

| Pin Num | Description |
|---------|-------------|
| 1       | DCD         |
| 2       | RXD         |
| 3       | TXD         |
| 4       | DTR         |
| 5       | GND         |
| 6       | DSR         |
| 7       | RTS         |
| 8       | CTS         |
| 9       | +5V         |



▪ COM3(RJ45)

| Pin Num | Description |
|---------|-------------|
| 1       | VSERIAL     |
| 2       | DSR         |
| 3       | TXD         |
| 4       | RXD         |
| 5       | RTS         |
| 6       | CTS         |
| 7       | GND         |
| 8       | DTR         |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle

Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
02. Mainboard Overview

USB & LAN Ports



USB Port(TYPE A)

| Pin Num | Description |
|---------|-------------|
| 1       | VSUB(+5V)   |
| 2       | D-          |
| 3       | D+          |
| 4       | GND         |



LAN Port(RJ45)

| Pin Num | Description |
|---------|-------------|
| 1       | MDI [0] +   |
| 2       | MDI [0] -   |
| 3       | MDI [1] +   |
| 4       | MDI [1] -   |
| 5       | MDI [2] +   |
| 6       | MDI [2] -   |
| 7       | MDI [3] +   |
| 8       | MDI [3] -   |



# SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle

## Appendix A System Set-Up

## Appendix B System Structure

- System Block
- Mainboard Overview
- Exploded View

### System Structure


## 02. Mainboard Overview

### Cash Drawer Port / Cash Drawer Power Selection Switch



#### ▪ Cash Drawer Port (RJ11)

| Pin Num | Description       |
|---------|-------------------|
| 1       | GND               |
| 2       | DRAWER#1          |
| 3       | DRW_COMP          |
| 4       | VDRW(+12V / +24V) |
| 5       | DRAWER#2          |
| 6       | GND               |



#### ▪ Power Selection Switch for Cash Drawer (CN9 on Parallel PCB)

| Jumper Setting | Voltage       |
|----------------|---------------|
| 1 – 2 Short    | 12V (Default) |
| 2 – 3 Short    | 24V           |



## SPT-7000

Introduction ▶

System Installation ▶

System Use ▶

System Expansion  
& Dismantle ▶

Appendix A  
System Set-Up

Appendix B  
System Structure ▼

System Block  
• Mainboard Overview  
Exploded View

### System Structure

## 02. Mainboard Overview

### Dc Power Jack



#### ▪ Adapter Output +12v

| Pin Num | Description |
|---------|-------------|
| 1       | NC          |
| 2       | +12V        |
| 3       | GND         |



SPT-7000

Introduction

System Installation

System Use

System Expansion  
& Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

MAIN



| NO | PART CODE        | PARTS NAME                           | Q'TY | Serviceable | REMARK        |
|----|------------------|--------------------------------------|------|-------------|---------------|
| 1  | JK72-20551A      | PMO-BRAND FRONT                      | 1    | Y           | OPTION        |
| A  | -                | ASSY FRONT DISPLAY                   | 1    | N           |               |
| B  | QMR-S730(STD)    | ASSY MSR                             | 1    | Y           | OPTION        |
| 2  | JK70-20215A      | IPR-PLATE REAR                       | 1    | Y           |               |
| 3  | S600600005A      | SCREW-ASS'Y TAP TITE BH+M4,L8        | 5    | Y           |               |
| 4  | S600100056A      | SCREW-MACHINE HAND M3,L10            | 2    | Y           |               |
| C  | -                | ASSY FRAME STAND                     | 1    | N           |               |
| D  | -                | ASSY FRAME MAIN                      | 1    | N           |               |
| E  | -                | ASSY SUPPORT LEFT                    | 1    | N           |               |
| 5  | JK70-20200A      | IPR-SUPPORT RIGHT                    | 1    | Y           |               |
| 6  | JK39-40893A      | HW-HARNES GROUND                     | 1    | Y           |               |
| 7  | S600100016A      | SCREW-MACHINE-PWHM3,L4               | 1    | Y           |               |
| 8  | S600100010A      | SCREW-MACHINE-FH+M4,L10              | 6    | Y           |               |
| 9  | S600200005A      | SCREW-TAPPING-PWHM3,L10              | 5    | Y           |               |
| 10 | S600200036A      | SCREW-TAPPING-FHLM4,L10              | 6    | Y           |               |
| 11 | JK72-20519A      | PMO-COVER LEFT                       | 1    | Y           |               |
| 12 | JK72-20540A      | PMO-DUMMY ANT                        | 1    | Y           | OPTION        |
| 13 | JK72-20522A      | PMO-COVER POWER                      | 1    | Y           |               |
| 14 | JK72-20520A      | PMO-COVER RIGHT                      | 1    | Y           |               |
| F  | -                | ASSY SUPPORT CROSS                   | 1    | N           |               |
| L  | -                | ASSY HDD                             | 1    | N           |               |
| 15 | S600100037A      | SCREW-MACHINE COIN M3,L6             | 1    | Y           |               |
| 16 | JK72-20513A      | PMO-COVER HDD                        | 1    | Y           |               |
| K  | -                | ASSY COVER SPEAKER                   | 1    | N           |               |
| GH | QPT-S733(STD)    | ASSY PRINTER 3"                      | 1    | Y           | OPTION        |
|    | QPT-S732(STD)    | ASSY PRINTER 2"                      | 1    | Y           |               |
| 17 | JK72-20529A      | PMO-COVER CUTTER                     | 1    | Y           | OPTION        |
| 18 | JK72-20531A      | PMO-DUMMY PRINTER                    | 1    | Y           | OPTION        |
| I  | QDK-T705         | ASSY DALLAS_5KEY_ONLY                | 1    | Y           | OPTION        |
|    | QDK-T710         | ASSY DALLAS_10KEY_ONLY               |      |             |               |
|    | QSC-700(STD)     | ASSY SCANNER_ONLY                    |      |             |               |
|    | QSC-SM700(STD)   | ASSY SCANNER&SMART CARD              |      |             |               |
|    | QSM-700(STD)     | ASSY SMART CARD_ONLY                 |      |             |               |
|    | QDK-SC705(STD)   | ASSY DALLAS&SCANNER_5KEY             |      |             |               |
|    | QDK-SC710(STD)   | ASSY DALLAS&SCANNER_10KEY            |      |             |               |
|    | QDK-SM705(STD)   | ASSY DALLAS&SMART CARD_5KEY          |      |             |               |
|    | QDK-SM710(STD)   | ASSY DALLAS&SMART CARD_10KEY         |      |             |               |
|    | QDK-SS705(STD)   | ASSY DALLAS&SCANNER&SMART CARD_5KEY  |      |             |               |
|    | QDK-SS710(STD)   | ASSY DALLAS&SCANNER&SMART CARD_10KEY |      |             |               |
| J  | JK96-10380A      | ASSY-DUMMY FRONT                     | 1    | Y           | OPTION        |
| N  | -                | ASSY POWER SMPS                      | 1    | N           |               |
| 19 | S600100037A      | SCREW-MACHINE COIN M3,L6             | 1    | Y           |               |
| M  | -                | ASSY MAIN BOARD                      | 1    | N           |               |
| 20 | S600100016A      | SCREW-MACHINE-PWHM3,L4               | 2    | Y           |               |
| 21 | JK72-20528A      | PMO-HOLDER CABLE                     | 1    | Y           | OPTION        |
| O  | JK95-70385A      | ASSY COVER REAR                      | 1    | Y           |               |
| P  | JK95-70384A      | ASSY COVER BOTTOM                    | 1    | Y           |               |
| Q  | QCD-S7L15NB(STD) | ASSY DUAL DISPLAY(15")               | 1    | Y           | OPTION        |
| R  | QCD-S7L7NB(STD)  | ASSY DUAL DISPLAY(7")                | 1    | Y           | OPTION        |
| S  | QCD-S7V202(STD)  | ASSY CDP_CHARACTER_20+2              | 1    | Y           | OPTION        |
|    | QCD-S7G256(STD)  | ASSY CDP_GRAPHIC_256+32              | 1    | Y           |               |
| 22 | JK72-20524A      | PMO-DUMMY VFD                        | 1    | Y           | OPTION        |
| 23 | JK72-20510A      | PMO-COVER TOP                        | 1    | Y           |               |
| 24 | JK39-40881A      | HW-HARNES MAIN POWER                 | 1    | Y           |               |
| 25 | JK39-40882A      | HW-HARNES PRT POWER                  | 1    | Y           |               |
| 26 | JK39-40875A      | HW-HARNES HUB                        | 1    | Y           |               |
| 27 | JK39-40877A      | HW-HARNES MAIN OSD                   | 1    | Y           |               |
| NO | PART CODE        | PARTS NAME                           | Q'TY | Serviceable | REMARK        |
| 28 | JK95-70196A      | ELA UNIT-HOLDER DALLAS               | 1    | Y           | STRAIGHT TYPE |
| 29 | JK39-20004A      | CBF POWER CORD                       | 1    | Y           | EUROPE        |
|    | JK39-20004B      |                                      |      |             | USA           |
|    | JK39-20004C      |                                      |      |             | UK            |
|    | JK39-20004D      |                                      |      |             | AUSTRALIA     |
|    | JK39-20004E      |                                      |      |             | KOREA         |
|    | JK39-20004F      |                                      |      |             | SOUTH AFRICA  |
|    | JK39-20004G      |                                      |      |             | ISRAEL        |
|    | JK39-20004H      |                                      |      |             | INDIA         |
|    | JK39-20004J      |                                      |      |             | ARGENTINA     |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

FRONT DISPLAY



| NO  | PART CODE   | PARTS NAME               | Q'TY | Serviceable | REMARK |
|-----|-------------|--------------------------|------|-------------|--------|
| A1  | JK72-20544A | PMO-FRONT DISPLAY        | 1    | Y           |        |
| A2  | JK73-20015A | RMO-WATER PROOF          | 1    | Y           |        |
| A3  | JK72-20553A | PMO-GUIDE TOUCH          | 6    | Y           |        |
| A4  | JK95-70378E | HW-TOUCH PANEL           | 1    | Y           |        |
| A5  | JK07-00014A | HW-LCD-TFT               | 1    | Y           |        |
| A6  | JK70-20217A | IPR-BRKT DISPLAY         | 1    | Y           |        |
| A7  | JK92-10001E | HW-MSR JOINT BOARD       | 1    | Y           |        |
| A8  | S4401001171 | HW-INVERTER MODULE       | 1    | Y           |        |
| A9  | S600100016A | SCREW-MACHINE:PWH,M3,L4  | 2    | Y           |        |
| A10 | S600100016A | SCREW-MACHINE:PWH,M3,L4  | 3    | Y           |        |
| A11 | JK92-10001C | HW-TOUCH BOARD(ELO)      | 1    | Y           |        |
| A12 | S600100016A | SCREW-MACHINE:PWH,M3,L4  | 2    | Y           |        |
| A13 | S600300020A | SCREW-TAPTITE:BH,M3,L10  | 12   | Y           |        |
| A14 | S600100044A | SCREW-MACHINE:PH,M3,L5   | 4    | Y           |        |
| A15 | JK72-20546A | PMO-REAR BOTTOM          | 1    | Y           |        |
| A16 | JK72-20545A | PMO-REAR TOP             | 1    | Y           |        |
| A17 | S600100037A | SCREW-MACHINE COIN M3,L6 | 1    | Y           |        |
| A21 | JK39-40879A | HW-HARNESS- LVDS         | 1    | Y           |        |
| A19 | JK39-40874A | HW-HARNESS- MSR          | 1    | Y           |        |
| A18 | JK39-40872A | HW-HARNESS- TUOCH        | 1    | Y           |        |
| A20 | JK39-40878A | HW-HARNESS- INVERTER     | 1    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

MSR



| NO  | PART CODE   | PARTS NAME                | Q'TY | Serviceable | REMARK |
|-----|-------------|---------------------------|------|-------------|--------|
| B1  | JK72-20554A | PMO-COVER MSR UPPER       | 1    | Y           |        |
| B2  | JK72-20556A | PMO-LED MSR               | 1    | Y           |        |
| B3  | JK48-00007A | HW-MSR MODULE             | 1    | Y           |        |
| B4  | JK70-20218A | IPR-HOLDER MSR            | 1    | Y           |        |
| B5  | JK92-10001F | HW-MSR BOARD              | 1    | Y           |        |
| B6  | JK72-20555A | PMO-COVER MSR LOWER       | 1    | Y           |        |
| B7  | S600200005A | SCREW-TAPPING:PWH,M3,L10  | 2    | Y           |        |
| B8  | S600100016A | SCREW-MACHINE:PWH,+,M3,L4 | 2    | Y           |        |
| B9  | S600100016A | SCREW-MACHINE:PWH,+,M3,L4 | 2    | Y           |        |
| B10 | S600200015A | SCREW-TAPPING:BH,+,M3,L12 | 2    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

STAND



| NO | PART CODE   | PARTS NAME                   | Q'TY | Serviceable | REMARK |
|----|-------------|------------------------------|------|-------------|--------|
| C1 | JK95-70378A | IPR-FRAME STAND              | 1    | Y           |        |
| C2 | JK72-20521A | PMO-COVER FRONT              | 1    | Y           |        |
| C3 | S600100049A | SCREW-MACHINE:PWH,M3,L6      | 1    | Y           |        |
| C4 | JK72-20558A | PMO-PROTECT POWER            | 1    | Y           |        |
| C5 | S600100049A | SCREW-MACHINE:PWH,M3,L6      | 2    | Y           |        |
| C6 | S600600005A | SCREW-ASS'Y MACH:WT,BH,M4,L8 | 1    | Y           |        |
| C7 | JK95-70429A | HW-HARNESS-INLET POWER       | 1    | Y           |        |
| C8 | S600100027A | SCREW-MACHINE:BH,M3,L10      | 2    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

FRAME MAIN



| NO | PART CODE   | PARTS NAME               | Q'TY | Serviceable | REMARK |
|----|-------------|--------------------------|------|-------------|--------|
| D1 | JK72-20527A | PMO-FRAME MAIN           | 1    | Y           |        |
| D2 | JK70-20211A | IPR-BRKT POWER           | 1    | Y           |        |
| D3 | S600200005A | SCREW-TAPPING:PWH,M3,L10 | 2    | Y           |        |
| D4 | JK92-10002A | HW-POWER BOARD           | 1    | Y           |        |
| D5 | S600200005A | SCREW-TAPPING:PWH,M3,L10 | 1    | Y           |        |
| D6 | JK92-10002D | HW-WIFI BOARD            | 1    | Y           |        |
| D7 | S600200005A | SCREW-TAPPING:PWH,M3,L10 | 1    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

SUPPORT LEFT



| NO | PART CODE   | PARTS NAME              | Q'TY | Serviceable | REMARK |
|----|-------------|-------------------------|------|-------------|--------|
| E1 | JK95-70504A | ASSY-SUPPORT LEFT       | 1    | Y           |        |
| E2 | JK95-70505A | ASSY-HEATSINK HDD       | 1    | Y           |        |
| E3 | S600100049A | SCREW-MACHINE:PWH,M3,L6 | 2    | Y           |        |
| E4 | JK70-20219A | IPR-PLATE GROUND        | 1    | Y           |        |
| E5 | S600100016A | SCREW-MACHINE:PWH,M3,L4 | 1    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

SUPPORT CROSS



| NO  | PART CODE   | PARTS NAME                      | Q'TY | Serviceable | REMARK |
|-----|-------------|---------------------------------|------|-------------|--------|
| F1  | JK95-70506A | ASSY-SUPPORT CROSS              | 1    | Y           |        |
| F2  | JK92-10002F | HW-VFD BOARD                    | 1    | Y           |        |
| F3  | S600200005A | SCREW-TAPPING:PWH,M3,L10        | 1    | Y           |        |
| F4  | JK75-40014A | MEC-HINGE ASS'Y                 | 1    | Y           |        |
| F5  | S600600005A | SCREW-ASS'Y TAPTITE:WT,BH,M4,L8 | 6    | Y           |        |
| F6  | JK72-20511A | PMO-HOLDER DISPLAY              | 1    | Y           |        |
| F7  | S600200005A | SCREW-TAPPING:PWH,M3,L10        | 1    | Y           |        |
| F8  | JK72-20548A | PMO-HINGE TOP                   | 1    | Y           |        |
| F9  | JK72-20549A | PMO-HINGE BOTTOM                | 1    | Y           |        |
| F10 | JK39-40873A | HW-HARNESS VFD WIFI             | 1    | Y           |        |



# SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


## Appendix A System Set-Up

## Appendix B System Structure

- System Block
- Mainboard Overview
- Exploded View

## System Structure 03. Exploded View

### PRINTER



| NO  | PART CODE   | PARTS NAME                   | Q'TY | Serviceable | REMARK |
|-----|-------------|------------------------------|------|-------------|--------|
| G1  | JK72-20534A | PMO-PAPER SUPPLY             | 1    | Y           |        |
| G2  | JK39-40745A | HW-HARNESS-PRT POWER         | 1    | Y           |        |
| G3  | JK92-10009A | HW-PRT OSD BOARD             | 1    | Y           |        |
| G4  | JK72-20541A | PMO-HOLDER POWER             | 1    | Y           |        |
| G5  | S600200006A | SCREW-TAPPING:PWH,+,2,M3,L8  | 2    | Y           |        |
| G6  | JK72-20533A | PMO-LOCK SUPPLY              | 1    | Y           |        |
| G7  | JK72-20536A | PMO-GUIDE PAPER L            | 1    | Y           |        |
| G8  | JK72-20537A | PMO-GUIDE PAPER R            | 1    | Y           |        |
| G9  | JK72-20535A | PMO-PAPER PARTION            | 1    | Y           | OPTION |
| G10 | JK95-70368C | ASSY PRINTER MAIN            | 1    | Y           |        |
| G11 | S600200005A | SCREW-TAPPING:PWH,+,2,M3,L10 | 4    | Y           |        |
| G12 | JK70-20202A | IPR-BRKT CUTTER              | 1    | Y           |        |
| G13 | S600100016A | SCREW-MACHINE:PWH,+,M3,L4    | 2    | Y           |        |
| G14 | JK92-10010A | HW-PRINTER BOARD             | 1    | Y           |        |
| G15 | S600200006A | SCREW-TAPPING:PWH,+,2,M3,L8  | 2    | Y           |        |
| G16 | JK39-40883A | HW-HARNESS PRT OSD           | 1    | Y           |        |
| G17 | JK70-30035A | SPRING-LOCK SUPPLY           | 1    | Y           |        |
| H1  | JK95-70507A | ASSY-COVER PRINTER           | 1    | Y           |        |
| H2  | JK72-20532A | PMO-FEED BUTTON              | 1    | Y           |        |
| H3  | JK70-20203A | IPR-BRKT FEED                | 1    | Y           |        |
| H4  | JK95-70393A | ASSY PRINTER ROLLER          | 1    | Y           |        |
| H5  | S600100054A | SCREW-MACHINE:BH,M3,L8       | 2    | Y           |        |
| H6  | JK95-70508A | ASSY-COVER GROUND            | 1    | Y           |        |
| H7  | S600200006A | SCREW-TAPPING:PWH,+,2,M3,L8  | 1    | Y           |        |
| H8  | JK39-40894A | HW-HARNESS GROUND            |      |             |        |
| G   | JK95-70394A | ASSY-PAPER SUPPLY            | 1    | Y           |        |
| H   | JK95-70392A | ASSY-COVER PRINTER           | 1    | Y           |        |
| GH1 | JK70-70057A | ICT-SHAFT PRINTER            | 1    | Y           |        |
| GH2 | JK70-30028A | SPRING-COVER PRINTER         | 1    | Y           |        |
| GH3 | S604400007A | E-RING                       | 1    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

COVER SCANNER



| NO  | PART CODE   | PARTS NAME                  | Q'TY | Serviceable | REMARK |
|-----|-------------|-----------------------------|------|-------------|--------|
| I1  | JK72-20514A | PMO-COVER SCANNER           | 1    | Y           |        |
| I2  | JK72-20293A | PMO-KNOB LOCK               | 1    | Y           |        |
| I3  | JK70-20214A | IPR-BRKT LOCK               | 1    | Y           |        |
| I4  | S600200023A | SCREW-TAPPING:PWH,M3,L6,WØ1 | 3    | Y           |        |
| I5  | JK92-01735A | HW-HUB BOARD                | 1    | Y           | OPTION |
| I6  | S600200006A | SCREW-TAPPING:PWH,M3,L8     | 2    | Y           | OPTION |
| I7  | S1109000002 | HW-SMART CARD READER        | 1    | Y           | OPTION |
| I8  | S600200007A | SCREW-TAPPING:RH,M3,L6      | 2    | Y           | OPTION |
| I9  | JK70-20203A | IPR-BRKT FEED               | 1    | Y           |        |
| I10 | JK72-20518A | PMO-POWER BUTTON            | 1    | Y           |        |
| I11 | JK72-20517A | PMO-POWER LED               | 1    | Y           |        |
| I12 | JK92-10002B | HW-MAIN OSD BOARD           | 1    | Y           |        |
| I13 | S600200006A | SCREW-TAPPING:PWH,M3,L8     | 2    | Y           |        |
| I14 | JK70-20213A | IPR-BRKT SCANNER LOCK       | 1    | Y           |        |
| I15 | S600200006A | SCREW-TAPPING:PWH,M3,L8     | 2    | Y           |        |
| I16 | JK46-00022A | HW-UNIT-SCANNER             | 1    | Y           | OPTION |
| I17 | JK70-20228A | IPR-BRKT SCANNER            | 1    | Y           | OPTION |
| I18 | S600200006A | SCREW-TAPPING:PWH,M3,L8     | 2    | Y           | OPTION |
| I19 | S600100021A | SCREW-MACHINE:RH,M2,L4      | 3    | Y           | OPTION |
| I20 | JK72-20404A | PMO-CAP MSR                 | 1    | Y           | OPTION |
| I21 | JK72-20403A | PMO-CAP DALLAS              | 1    | Y           | OPTION |
| I22 | JK95-70134D | HW-ELA UNIT-iBUTTON PROBE   | 1    | Y           | OPTION |
| I23 | JK73-11026A | RMO-PAD BOARD               | 3    | Y           | OPTION |
| I24 | JK70-20229A | IPR-BRKT FPR                | 1    | Y           | OPTION |
| I25 | S600200006A | SCREW-TAPPING:PWH,M3,L8     | 1    | Y           | OPTION |
| I26 | JK72-20402A | PMO-CAP FPR                 | 1    | Y           | OPTION |
| I27 | S600100048A | SCREW-MACHINE:BH,M2X14      | 2    | Y           | OPTION |
| I28 | JK46-00020A | HW-FINGER PRINTER           | 1    | N           | OPTION |
| I29 | JK39-40758A | HW-HARNESS-GND SCANNER      | 1    | Y           |        |
| I30 | JK95-70428A | HW-HARNESS SCANNER          | 1    | Y           | OPTION |
| I31 | JK39-40820A | HW-HARNESS-FINGER PRINT     | 1    | Y           | OPTION |
| I32 | JK39-40821A | HW-HARNESS-SCR              | 1    | Y           | OPTION |



SPT-7000

Introduction

System Installation

System Use

System Expansion  
& Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

DUMMY FRONT



| NO  | PART CODE   | PARTS NAME                   | Q'TY | Serviceable | REMARK |
|-----|-------------|------------------------------|------|-------------|--------|
| J1  | JK72-20515A | PMO-DUMMY FRONT              | 1    | Y           |        |
| J2  | JK72-20293A | PMO-KNOB LOCK                | 1    | Y           |        |
| J3  | JK70-20214A | IPR-BRKT LOCK                | 1    | Y           |        |
| J4  | S600200023A | SCREW-TAPPING:PWH,M3,L6,WØ10 | 3    | Y           |        |
| J5  | JK70-20203A | IPR-BRKT FEED                | 1    | Y           |        |
| J6  | JK72-20518A | PMO-POWER BUTTON             | 1    | Y           |        |
| J7  | JK72-20517A | PMO-POWER LED                | 1    | Y           |        |
| J8  | JK92-10002B | HW-MAIN OSD BOARD            | 1    | Y           |        |
| J9  | S600200006A | SCREW-TAPPING:PWH,M3,L8      | 2    | Y           |        |
| J10 | JK70-20213A | IPR-BRKT SCANNER LOCK        | 1    | Y           |        |
| J11 | S600200006A | SCREW-TAPPING:PWH,M3,L8      | 2    | Y           |        |



SPT-7000

Introduction

System Installation

System Use

System Expansion  
& Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

COVER SPEAKER



| NO | PART CODE   | PARTS NAME              | Q'TY | Serviceable | REMARK |
|----|-------------|-------------------------|------|-------------|--------|
| K1 | JK72-20512A | PMO-COVER SPEAKER       | 1    | Y           |        |
| K2 | JK73-11040A | RMO-COVER USB           | 2    | Y           |        |
| K3 |             | MEC-USB BOARD           | 1    | Y           |        |
| K4 | S600200006A | SCREW-TAPPING:PWH,M3,L8 | 1    | Y           |        |
| K5 | S3004000001 | HW-UNIT-SPEAKER         | 1    | Y           |        |
| K6 | JK72-20542A | PMO-HOLDER SPEAKER      | 1    | Y           |        |
| K7 | S600200006A | SCREW-TAPPING:PWH,M3,L8 | 1    | Y           |        |
| K8 | JK39-40870A | HW-HARNESS USB          | 1    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

HDD ASSY



| NO | PART CODE   | PARTS NAME                   | Q'TY | Serviceable | REMARK |
|----|-------------|------------------------------|------|-------------|--------|
| L1 | JK70-20210A | IPR-BRKT HDD                 | 1    | Y           |        |
| L2 | JK50-00002B | UNIT-HDD                     | 1    | Y           | OPTION |
| L3 | S39090001A  | HARNESS-SATA                 | 1    | Y           | OPTION |
| L4 | JK73-11017A | RMO-RUBBER INSULATOR         | 4    | Y           | OPTION |
| L5 | S600100036A | SCREW-MACHINE HAND:M3,L4,HD8 | 4    | Y           | OPTION |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

BRKT MAIN



| NO  | PART CODE   | PARTS NAME              | Q'TY | Serviceable | REMARK |
|-----|-------------|-------------------------|------|-------------|--------|
| M1  | JK95-70509A | ASSY-BRKT INTERFACE     | 1    | Y           |        |
| M2  | JK95-70510A | ASSY-BRKT MAIN          | 1    | Y           |        |
| M3  | JK73-11042A | WIRE HOLDER             | 2    | Y           |        |
| M4  | JK92-10002E | HW-DRAWER BOARD         | 1    | Y           |        |
| M5  | S600100016A | SCREW-MACHINE:PWH,M3,L4 | 2    | Y           |        |
| M6  | JK92-10001A | HW-PARALLEL BOARD       | 1    | Y           |        |
| M7  | S600100016A | SCREW-MACHINE:PWH,M3,L4 | 4    | Y           |        |
| M8  | S390800004A | HW-HARNESS IDE          | 1    | Y           |        |
| M9  | JK92-10011A | HW-CFAST BOARD          | 1    | Y           | OPTION |
| M10 | S600100016A | SCREW-MACHINE:PWH,M3,L4 | 2    | Y           | OPTION |
| M11 | S39090001A  | HARNESS-SATA            | 1    | Y           | OPTION |
| M12 | JK92-10732A | HW-RAISER BOARD         | 1    | Y           | OPTION |
| M13 | S600100016A | SCREW-MACHINE:PWH,M3,L4 | 3    | Y           |        |
| M14 | JK95-70441A | HW-MOTHER BOARD         | 1    | Y           |        |
| M15 | S600100016A | SCREW-MACHINE:PWH,M3,L4 | 2    | Y           |        |
| M16 | S600100031A | SCREW-MACHINE:FH,M3,L4  | 3    | Y           |        |
| M17 | JK39-40871A | HW-HARNESS DRAWER       | 1    | Y           |        |
| M18 | JK39-40824A | HW-HARNESS SPK JOIN     | 1    | Y           |        |
| M19 | JK39-40880A | HW-HARNESS LPT          | 1    | Y           |        |
| M20 | JK95-70215A | HW-DDR3 2G RAM          | 1    | Y           | OPTION |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

POWER



| NO | PART CODE   | PARTS NAME                   | Q'TY | Serviceable | REMARK |
|----|-------------|------------------------------|------|-------------|--------|
| N1 | JK70-20208A | IPR-BRKT POWER HANDLE        | 1    | Y           |        |
| N2 | JK95-70511A | ASSY-BRKT POWER BOTTOM (60W) | 1    | Y           | OPTION |
|    | JK95-70523A | ASSY-BRKT POWER BOTTOM (80W) |      |             |        |
| N3 | S600100016A | SCREW-MACHINE:PWH,M3,L4      | 2    | Y           |        |
| N4 | S600100016A | SCREW-MACHINE:PWH,M3,L4      | 2    | Y           |        |
| N5 | JK95-70424A | HW-MAIN POWER(60W)           | 1    | Y           | OPTION |
|    | JK95-70425A | HW-MAIN POWER(80W)           |      |             |        |
| N6 | JK95-70427A | HW-PRINTER POWER(60W)        | 1    | Y           |        |
| N7 | JK95-70512A | ASSY-BRKT POWER TOP (60W)    | 1    | Y           | OPTION |
|    | JK95-70522A | ASSY-BRKT POWER TOP (80W)    |      |             |        |
| N8 | S600100016A | SCREW-MACHINE:PWH,M3,L4      | 1    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

COVER REAR



| NO | PART CODE   | PARTS NAME                 | Q'TY | Serviceable | REMARK |
|----|-------------|----------------------------|------|-------------|--------|
| O1 | JK72-20557A | PMO-COVER REAR             | 1    | Y           |        |
| O2 | JK68-40219A | LABEL(R)-CFAST             | 1    | Y           |        |
| O3 | JK72-20523A | PMO-COVER CF               | 1    | Y           |        |
| O4 | JK72-20516A | PMO-LOCK BUTTON            | 2    | Y           |        |
| O5 | JK70-20212A | IPR-BRKT BUTTON            | 2    | Y           |        |
| O6 | S600200006A | SCREW-TAPPING: PWH,2,M3,L8 | 2    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

COVER BOTTOM



| NO | PART CODE   | PARTS NAME                | Q'TY | Serviceable | REMARK |
|----|-------------|---------------------------|------|-------------|--------|
| P1 | JK72-20526A | PMO-COVER BOTTOM          | 1    | Y           |        |
| P2 | JK72-20525A | PMO-COVER WIRE            | 1    | Y           |        |
| P3 | S600200006A | SCREW-TAPPING:PWH,2,M3,L8 | 3    | Y           |        |
| P4 | JK72-20516A | PMO-LOCK BUTTON           | 2    | Y           |        |
| P5 | JK70-20212A | IPR-BRKT BUTTON           | 2    | Y           |        |
| P6 | S600200006A | SCREW-TAPPING:PWH,2,M3,L8 | 2    | Y           |        |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle



Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

OPTION DUAL



| NO         | PART CODE   | PARTS NAME                   | Q'TY | Serviceable | REMARK |
|------------|-------------|------------------------------|------|-------------|--------|
| Q          | QCD-S7L15NB | OPTION 15"DUAL               | 1    | Y           | OPTION |
| Q1         | JK72-20544A | PMO-FRONT DISPLAY            | 1    | Y           |        |
| Q2         | JK92-01736A | HW-DUAL OSD BOARD            | 1    | Y           |        |
| Q3         | JK72-20551A | PMO-BRAND FRONT              | 1    | Y           | OPTION |
| Q4         | JK72-20547A | PMO-BUTTON                   | 1    | Y           |        |
| Q5         | JK73-20015A | RMO-WATER PROOF              | 1    | Y           |        |
| Q6         | JK07-00014A | HW-LCD-TFT                   | 1    | Y           |        |
| Q7         | S600100044A | SCREW-MACHINE:PH,M3,L5       | 4    | Y           |        |
| Q8         | S600300020A | SCREW-TAPTITE:BH,M3,L10      | 12   | Y           |        |
| Q9         | S600100016A | SCREW-MACHINE:PWH,M3,L4      | 2    | Y           |        |
| Q10        | S4401001171 | HW-INVATER MODULE            | 1    | Y           |        |
| Q11        | JK95-70431A | ASSY-BRKT DISPLAY DUAL       | 1    | Y           |        |
| Q12        | JK97-00016B | HW-UNIT AD BOARD             | 1    | Y           |        |
| Q13        | S600100016A | SCREW-MACHINE:PWH,M3,L4      | 4    | Y           |        |
| Q14        | JK72-20546B | PMO-REAR BOTTOM              | 1    | Y           |        |
| Q15        | JK72-20552A | PMO-DUMMY MSR                | 1    | Y           | OPTION |
| Q16        | JK72-20545A | PMO-REAR TOP                 | 1    | Y           |        |
| Q17        | S600100036A | SCREW-MACHINE HAND M3,L6     | 1    | Y           |        |
| Q18        | S600600005A | SCREW-ASS'Y TAPTITE:BH,M4,L8 | 5    | Y           |        |
| Q19        | JK70-20215B | IPR-PLATE REAR               | 1    | Y           |        |
| Q20        | JK72-20548A | PMO-HINGE TOP                | 1    | Y           |        |
| Q21        | S600600005A | SCREW-ASS'Y TAPTITE:BH,M4,L8 | 6    | Y           |        |
| Q22        | JK75-40014A | MEC-HINGE ASS'Y              | 1    | Y           |        |
| Q23        | JK72-20550A | PMO-HOLDER DUAL              | 1    | Y           |        |
| Q24        | JK70-20216A | IPR-BRKT HINGE               | 1    | Y           |        |
| Q25        | S600200005A | SCREW-TAPPING:PWH,M3,L10     | 2    | Y           |        |
| Q26        | S600100056A | SCREW-MACHINE HAND M3,L10    | 2    | Y           |        |
| Q27        | JK72-20549A | PMO-HINGE BOTTOM             | 1    | Y           |        |
| Q28        | JK39-40792B | HW-HARNESS-VGA CABLE         | 1    | Y           |        |
| Q29        | JK39-40791A | HW-HARNESS-LCD POWER         | 1    | Y           |        |
| Q30        | JK39-40798A | HW-HARNESS-LVDS              | 1    | Y           |        |
| Q31        | JK39-40797A | HW-HARNESS-INVERTER          | 1    | Y           |        |
| Q32        | JK39-40876A | HW-HARNESS-DUAL OSD          | 1    | Y           |        |
| OPTION BOX |             |                              |      |             |        |
| Q33        | JK95-70425A | HW-MAIN POWER(80W)           | 1    | Y           | OPTION |
| Q34        | JK72-20528A | PMO-HOLDER CABLE             | 1    | Y           |        |
| Q35        | S600600005A | SCREW-ASS'Y TAPTITE:BH,M4,L8 | 4    | Y           |        |
| Q36        | S600100017A | SCREW-MACHINE:PWH,M3,L6      | 1    | Y           |        |
| Q37        | JK73-11053A | RMO-PAD POWER 80W            | 2    | Y           | OPTION |



SPT-7000

- Introduction
- System Installation
- System Use
- System Expansion & Dismantle


Appendix A  
System Set-Up

Appendix B  
System Structure

- System Block
- Mainboard Overview
- Exploded View

System Structure  
03. Exploded View

OPTION CDP 7INCH



| NO  | PART CODE   | PARTS NAME                  | Q'TY | Serviceable | REMARK |
|-----|-------------|-----------------------------|------|-------------|--------|
| S   | QCD-S4V202  | OPTION-CDP (CHARACTER)      | 1    | N           | OPTION |
|     | QCD-S4G256  | OPTION-CDP (GRAPHIC)        |      |             |        |
| S1  | JK72-20299A | PMO-WINDOW VFD              | 1    | Y           |        |
| S2  | JK68-40120A | LABEL(R)-VFD SHEET          | 1    | Y           |        |
| S3  | S600300020A | SCREW-TAPTITE               | 2    | Y           |        |
| S4  | JK46-00006A | UNIT-VFD MODULE (CHARACTER) | 1    | Y           |        |
|     | JK46-00007A | UNIT-VFD MODULE (GRAPHIC)   |      |             |        |
| S5  | JK72-20298A | PMO-REAR VFD(M)             | 1    | Y           |        |
| S6  | S600300020A | SCREW-TAPTITE               | 1    | Y           |        |
| S7  | JK72-20595A | PMO-HOLDER VFD              | 1    | Y           |        |
| S8  | JK72-20300A | PMO-REAR VFD DUMMY          | 1    | Y           |        |
| S9  | S600300020A | SCREW-TAPTITE               | 1    | Y           |        |
| S10 | JK75-40004A | MEC-HINGE ASSY              | 1    | Y           |        |
| S11 | JK39-40727A | HARNESS-POLE                | 1    | Y           |        |

| NO  | PART CODE   | PARTS NAME           | Q'TY | Serviceable | REMARK |
|-----|-------------|----------------------|------|-------------|--------|
| R   | QCD-S7L7NB  | OPTION 7" DUAL       | 1    | Y           | OPTION |
| R1  | JK72-20592A | PMO-LCD FRONT        | 1    | Y           |        |
| R2  | JK73-20016A | RMO-WATER PROOF(P)   | 1    | Y           |        |
| R3  | JK07-00023A | HW-DISPLAY-LCD       | 1    | Y           |        |
| R4  | JK73-11043A | RMO-RUBBER LCD       | 6    | Y           |        |
| R5  | JK70-20238A | IPR-BRKT LCD         | 1    | Y           |        |
| R6  | JK49-00003C | HW-7INCH AD B'D      | 1    | Y           |        |
| R7  | S600100016A | SCREW-MACHINE        | 4    | Y           |        |
| R8  | S600200006A | SCREW-TAPPING        | 4    | Y           |        |
| R9  | JK70-20240A | IPR-PLATE REAR(P)    | 1    | Y           |        |
| R10 | JK72-20596A | PMO-HOLDER HINGE(D)  | 1    | Y           |        |
| R11 | JK72-20593B | PMO-LCD REAR         | 1    | Y           |        |
| R12 | JK72-20595A | PMO-HOLDER VFD       | 1    | Y           |        |
| R13 | JK75-40004A | MEC-HINGE ASS'Y      | 2    | Y           |        |
| R14 | S600300020A | SCREW-TAPTITE        | 4    | Y           |        |
| R15 | JK72-20594A | PMO-BUTTON(P)        | 1    | Y           |        |
| R16 | JK72-20600A | PMO-COVER LED(P)     | 1    | Y           |        |
| R17 | JK39-60085A | HW-HARNESS-POWER     | 1    | Y           |        |
| R18 | JK39-60086A | HW-HARNESS-VGA CABLE | 1    | Y           |        |